

IDENTIFICATION

PRODUCT CODE: MAINDEC-Ø8-DHTDA-A-D
 REPLACES: MAINDEC-8E-D3AB-D


PRODUCT NAME: TD8E DECTAPE DIAGNOSTIC

DATE CREATED: NOVEMBER 1, 1972

MAINTAINER: DIAGNOSTIC GROUP

AUTHOR: E. STEINBERGER/B. HANSEN

COPYRIGHT © 1971, 1972
DIGITAL EQUIPMENT CORPORATION



1, ABSTRACT

TD8E DECTAPE DIAGNOSTIC IS A PROGRAM WHICH HAS BEEN WRITTEN TO CHECKOUT AND TEST TD8E DECTAPE CONTROLS WITH TU56 DECTAPE TRANSPORTS; THE PROGRAM TESTS THE BASIC FUNCTIONS OF THE CONTROL (IOT SKIPS, DATA TRANSFERS, ETC) AS WELL AS CHECKING THE ABILITY TO READ AND WRITE ON DECTAPE.

2, REQUIREMENTS

2,1 EQUIPMENT

PDP-8E
TD8E DECTAPE CONTROL
TU56 DECTAPE TRANSPORT (AT LEAST ONE)
ALL NECESSARY CABLES AND MODULES

2,2 STORAGE

THE PROGRAM OCCUPIES MEMORY FROM LOCATION 20 TO LOCATION 7177 AND USES LOCATIONS 7200 TO 7577 AS DATA BUFFER AREA.

2,3 PRELIMINARY PROGRAMS

NONE

#, LOADING PROCEDURE

3,1 METHOD

THE PROGRAM IS LOADED USING THE STANDARD BINARY LOADER TECHNIQUE.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

THE FOLLOWING IS A TABLE OF CONTROL SWITCH SETTINGS AND THEIR ACTION UPON THE PROGRAM:

SR	STATE	ACTION
0	1	LOOP ON CURRENT SUBTEST
	0	DON'T LOOP
1	1	LOOP ON CURRENT TEST
	0	DON'T LOOP
2	1	LOOP ON CONTROL TESTS
	0	DON'T LOOP
3	1	DON'T PRINT ERRORS
	0	PRINT ERRORS
4	1	DON'T HALT ON ERRORS
	0	HALT ON ERROR
5	1	
	0	
6	1	
	0	
7	1	
	0	
8	1	
	0	
9	1	
	0	
10	1	
	0	
11	1	SINGLE UNIT TRANSPORT
	0	DUAL UNIT TRANSPORT

4.2 STARTING ADDRESSES

0200	OPERATOR INTERVENTION TESTS
0201	CONTROL AND DATA TRANSFER TESTS
2100	SEARCH AND FIND ALL BLOCK NUMBERS
2200	DISPLAY BLOCK NUMBERS IN AC
2237	ROUTINE TO ROCK DECTAPE 0 (TIME DEPENDENT ON SWITCH REGISTER)
2400	READ AND CHECK THE MARK TRACK FROM ENDZONE TO ENDZONE
7200	IDT MODIFICATION PROGRAM

4.3 PROGRAM AND/OR OPERATOR ACTION

4.3.1 TO TEST "SELECT ERROR" AND "WRITE LOCK OUT"

4.3.1.1 DUAL TRANSPORTS

- A) SET SWITCH REGISTER TO 0200
- B) ON THE TRANSPORTS, SET ONE TRANSPORT TO UNIT 0, ON-LINE, WRITE LOCK; SET THE OTHER TRANSPORT TO UNIT 1, OFF-LINE.
- C) DEPRESS "LOAD ADDRESS", THEN "CLEAR", THEN "CONTINUE"; THE PROGRAM SHOULD TYPE "OK"
- D) REVERSE THE ROLES OF THE TWO TRANSPORTS AND REPEAT STEP C;
- E) SET BOTH TRANSPORTS TO UNIT 1, ON-LINE; DEPRESS "LOAD ADDRESS", THEN "CLEAR", THEN "CONTINUE"; THE PROGRAM SHOULD INDICATE NO UNIT 0 SELECTED
- F) PROCEED TO 4.3.2

4.3.1.2 SINGLE TRANSPORT

- A) SET SWITCH REGISTER TO 0200
- B) ON THE TRANSPORT, SET TO UNIT 0, ON-LINE, WRITE LOCK
- C) DEPRESS "LOAD", THEN "CLEAR", THEN "CONTINUE"; THE PROGRAM SHOULD TYPE "OK"
- D) PROCEED TO 4.3.2

4.3.2 TO TEST CONTROL AND ABILITY TO PERFORM DATA TRANSFERS

- A) SET SWITCH REGISTER TO 0201, DEPRESS "LOAD ADDRESS"

- B) SET SWITCH REGISTER PER 4,1, SET SR11 IF ONLY ONE TRANSPORT EXISTS OR ONLY ONE TRANSPORT IS TO BE TESTED,
- C) MOUNT A STANDARD PDP-8 DECTAPE (2702 BLOCKS, 201 WORDS PER BLOCK) ON EACH TRANSPORT TO BE TESTED WITH THE TAPES WRAPPED AT LEAST 2 TURNS ON EACH TAKE UP REEL, RESPECTIVELY,
- D) SET A TRANSPORT TO UNIT 0, ON-LINE, WRITE ENABLE; SET THE OTHER TRANSPORT (IF IT EXISTS OR IS TO BE TESTED) TO UNIT 1, ON -LINE, WRITE ENABLE,
- E) DEPRESS "CLEAR", THEN "CONTINUE", THE PROGRAM WILL PERFORM THE BASIC CONTROL TESTS ON THE TDBE, AND, IF SR2 IS A 0, PROCEED TO MOVE TAPE AND PERFORM DATA TRANSFERS TO AND FROM TAPE, CHECKING THE RESULTS;

4,3,3 TO MODIFY THE TDBE IOT SET TO HANDLE A CONTROL FOR UNITS OTHER THAN 0 AND 1,

- A) SET SWITCH REGISTER TO 7200, DEPRESS "LOAD ADDRESS"
- B) SET SWITCH REGISTER BITS 6, 7 AND 8 TO DEVICE SELECTOR BITS 6, 7, AND 8 OF THE CONTROL TO BE TESTED (4, 5, 6 OR 7)
- C) DEPRESS "CLEAR", THEN "CONTINUE", THE PROGRAM WILL MODIFY ALL TDBE IOT'S TO HANDLE THE SELECTED CONTROL,
- D) PERFORM ALL TESTS INDICATED IN 4,3,1 AND 4,3,2 ABOVE FOR THE SELECTED CONTROL SUBSTITUTING UNIT 2, 4 OR 6 FOR UNIT 0 AND UNIT 3, 5 OR 7 FOR UNIT 1 ABOVE,
- E) CAUTION- THE CODE TO CHANGE THE IOT'S IS IN THE DATA BUFFER AREA FOR THE DATA TRANSFER TESTS AND WILL BE DESTROYED WHEN THAT PORTION OF THE PROGRAM IS RUN, AN OVERLAY TAPE IS PROVIDED TO ALLOW THIS CODE TO BE READ BACK INTO MEMORY FOR RE-EXECUTION, MAINDEC-00-DHYDA-A-PB2

5, OPERATING PROCEDURE

5,1 OPERATIONAL SWITCH SETTINGS

SEE 4,1

5,2 SUBROUTINE ABSTRACTS

NONE

5,3 PROGRAM AND/OR OPERATOR ACTION

SEE 4,3

5,3,1 IF PROBLEMS ARE SUSPECTED IN THE CONTROL WHEN READING THE TIMING TRACK OFF OF DECTAPE INCLUDING SINGLE LINE FLAG AND QUAD LINE FLAG, A ROCK TAPE ROUTINE HAS BEEN PROVIDED AT LOCATION 2237 TO ALLOW SCOPING OF SINGLE LINE FLAG, QUAD LINE FLAG, UP-TO-SPEED, ETC.

(2237)

- A) SET SWITCH REGISTER TO 2237, DEPRESS "LOAD ADDRESS"
- B) SET SWITCH REGISTER TO 0070, DEPRESS "CLEAR" THEN "CONTINUE", THE DECTAPE ON UNIT 0 SHOULD START ROCKING.
- C) MODIFY SWITCH REGISTER SETTING TO INCREASE OR DECREASE "ROCK" PERIOD.
- D) CAUTION-IF THE NUMBER IN THE SWITCH REGISTER IS TOO SMALL, THE DECTAPE TRANSPORT WILL NOT GET UP TO SPEED BEFORE IT TURNS AROUND.

5,3,2 A ROUTINE HAS BEEN PROVIDED AT LOCATION 2100 TO ALLOW A DECTAPE TO BE RUN FROM ENDZONE TO ENDZONE COMPARING ALL BLOCK NUMBERS; TO RUN THIS ROUTINE, START THE COMPUTER AT LOCATION 2100, THE SR HAS NO AFFECT UPON THE ROUTINE, TO RUN UNIT 1 CHANGE THE CONTENTS OF UNIT (LOCATION 2234) TO 4000, A HALT WILL OCCUR AT LOCATION 2150 IF AN ERROR OCCURS, THE CONTENTS OF THE AC EQUALS THE BLOCK THAT WAS BEING SEARCHED FOR, PRESS "CONT" AND THE PROGRAM WILL HALT AT LOCATION 2153 WITH THE AC EQUAL TO THE BLOCK THAT WAS FOUND, PRESS "CONT" AGAIN, THE PROGRAM WILL RECYCLE UNTIL ANOTHER ERROR IS FOUND.

(2100)

5,3,3 A ROUTINE HAS BEEN PROVIDED AT LOCATION 2200 TO ALLOW A DECTAPE TO BE RUN FROM ENDZONE TO ENDZONE WITH THE BLOCK NUMBERS DISPLAYED IN THE AC, TO RUN THIS ROUTINE, START THE COMPUTER AT LOCATION 2200, THE SR HAS NO AFFECT UPON THE ROUTINE, TO RUN UNIT 1, CHANGE THE CONTENTS OF UNIT (LOCATION 2234) TO 4000, NO ERRORS ARE DETECTED.

(2200)

5,3,4 A ROUTINE HAS BEEN PROVIDED AT LOCATION 2400 TO ALLOW A DECTAPE TO BE RUN FROM ENDZONE TO ENDZONE WITH THE MARK TRACK FORMAT BEING CHECKED, AN ERROR HALT WILL OCCUR IF AN ERROR IS DETECTED, TO RUN THIS ROUTINE (ONLY ON UNIT 0), START THE COMPUTER AT LOCATION 2400, THE SR HAS NO AFFECT UPON THE ROUTINE.

(2400)

6, ERRORS

6,1 ERROR HALTS AND DESCRIPTION

MOST ERROR HALTS ARE PRECEDED BY AN ERROR TYPEOUT (UNLESS SR3 IS A 1). IF NO ERROR TYPEOUT OCCURS, CONSULT THE LISTING FOR THE CAUSE OF THE ERROR.

6,2 ERROR RECOVERY

MOST ERRORS (EXCEPT DATA ERRORS) CAN BE (SCOPED BY SETTING SR0 TO 1 AND DEPRESSING "CONTINUE"

DATA ERRORS CANNOT BE (SCOPED, BUT DATA TRANSFERS CAN BE CONTINUED BY DEPRESSING "CONTINUE".

6,3 IF TAPE RUNS OFF THE END

NORMALLY, TAPE WILL NOT RUN OFF THE END OF THE REEL UNLESS THE PROGRAM IS IN A (SCOPE LOOP OR A SELECT ERROR OCCURS WHEN A TAPE IS MOVING (THE OPERATOR SETTING BOTH TAPE UNITS TO THE SAME NUMBER DURING THE DATA TRANSFER TESTS).

IF TAPE RUNS OFF THE END AND THE PROGRAM HANGS AROUND LOCATION 0621, CHECK THE ABILITY TO READ THE TIMING TRACK INTO THE T08E CONTROL AND THE CIRCUITS RELATING TO THE TIMING PULSE GENERATOR.

IF TAPE RUNS OFF THE END AND THE PROGRAM HANGS AROUND LOCATION 1466, CHECK THE ABILITY TO READ THE MARK TRACK INTO THE T08E CONTROL AND THE CIRCUITS RELATING TO THE MARK TRACK REGISTER.

7, RESTRICTIONS

7,1 STARTING RESTRICTIONS

NONE IF PARAGRAPH 4,3 IS PROPERLY FOLLOWED;

7,2 OPERATING RESTRICTIONS

NONE IF PARAGRAPH 4,3 IS PROPERLY FOLLOWED;

8: MISCELLANEOUS

8.1 EXECUTION TIME - \approx 20 MIN (Transport SA=201)

THE EXECUTION TIME OF THE CONTROL TESTS IS NORMALLY LESS THAN 1 MINUTE, DEPENDING UPON THE POSITION OF TAPE ON UNIT 0;

THE EXECUTION TIME OF THE DATA TESTS DEPENDS ON WHETHER ONE OR TWO TRANSPORTS IS BEING EXERCISED, PASS "N" COMPLETE WILL BE PRINTED ON THE TELEPRINTER AFTER ALL DATA PATTERNS HAVE BEEN EXERCISED ONCE, (NORMALLY LESS THAN 1 HOUR PER PASS);

20 min Transport

9: PROGRAM DESCRIPTION

9.1 DATA REGISTER TEST (SA=0201)

IN THIS TEST THE DATA REGISTER IS CHECKED FOR ITS ABILITY TO BE LOADED AND READ; FIRST THE COMPLEMENT OF THE DATA TO BE CHECKED IS LOADED INTO THE DATA REGISTER, THEN THE DATA ITSELF IS LOADED INTO THE REGISTER; THIS IS DONE TO CHECK THAT ALL BITS CAN BE LOADED TO A 1 FROM A 0 AND TO A 0 FROM A 1; THE DATA IS THEN READ INTO THE AC AND CHECKED FOR ERRORS; AN INCREMENT PATTERN IS USED;

9.2 COMMAND REGISTER TEST (SA=0236)

IN THIS TEST THE COMMAND REGISTER IS CHECKED FOR ITS ABILITY TO BE LOADED AND READ; DATA IS LOADED INTO THE COMMAND REGISTER THEN READ IN THE AC AND CHECKED FOR ERRORS; A 400 INCREMENT PATTERN IS USED, THE STOP/GO BIT IS MASKED OUT;

9.3 INITIALIZE TEST (SA=0305)

THIS TESTS CHECKS THAT "CAP" CLEARS THE COMMAND REGISTER; THE C,R, IS LOADED WITH 6400, THEN "CAP" IS ISSUED; THE C,R, IS THEN READ AND CHECKED TO CONTAIN 0;

9.4 CHECK SDLC, SOLD, SDRG, AND SDRD AND AC CLEAR (SA=0400)

THIS TEST CHECKS THE AC CLEAR FUNCTION OF THE SDLC, SOLD, SDRG AND SDRD INSTRUCTION; THIS IS DONE BY SETTING THE AC TO 7777; THEN ISSUING THE APPROPRIATE IOT (ONE AT A TIME) AND CHECK TO SEE IF THE AC DID OR DID NOT CLEAR (SOLD DOES NOT CLEAR THE AC, THE OTHERS DO);

9.5 CHECK SINGLE LINE SKIP INSTRUCTION AND LOGIC TEST (SA=0600)

THIS TEST CHECKS THE SINGLE LINE FLAG LOGIC AND SKIP INSTRUCTION, IN PARTICULAR IT TESTS: SINGLE LINE FLAG CLEAR AFTER A "CAF"; SINGLE LINE FLAG SETS; SDSS DOES NOT CLEAR SINGLE LINE FLAG; CAF CLEARS SINGLE LINE FLAG; SOLD CLEARS SINGLE LINE FLAG; SDRG CLEARS SINGLE LINE FLAG; SDRD CLEARS SINGLE LINE FLAG; SDST, SDSQ, AND SDLC DOES NOT CLEAR SINGLE LINE FLAG.

9.6 CHECK QUAD LINE SKIP INSTRUCTION AND LOGIC TEST (SA=1024)

THIS TEST CHECKS THE QUAD LINE FLAG LOGIC AND SKIP INSTRUCTION; IN PARTICULAR IT TESTS: QUAD LINE FLAG CLEAR AFTER A "CAF"; QUAD LINE FLAG SETS AT PROPER TIME; SDSQ DOES NOT CLEAR QUAD LINE FLAG; CAF CLEARS QUAD LINE FLAG; SOLD CLEARS QUAD LINE FLAG; SDRG CLEARS QUAD LINE FLAG; SDRD CLEARS QUAD LINE FLAG; SDST, SDSQ, AND SDLC DOES NOT CLEAR QUAD LINE FLAG; ALL QUAD LINE FLAG COUNTER FLIP/FLOPS GET CLEARED (BY SOLD);

9.7 CHECK TIMING ERROR SKIP INSTRUCTION AND LOGIC TEST (SA=1315)

THIS TEST CHECKS THE TIMING ERROR LOGIC AND SKIP INSTRUCTION; IN PARTICULAR IT TESTS: TIMING ERROR CLEAR AFTER A "CAF"; TIMING ERROR SETS IN READ MODE (SDSQ SKIPS); SDST DOES NOT CLEAR TIMING ERROR; CAF CLEARS TIMING ERROR; TIMING ERROR STATUS BIT CAN BE READ INTO AC BY SDRG; SDLC CLEARS TIMING ERROR; TIMING ERROR SETS IN WRITE MODE (PERFORMED AT REVERSE ENDZONE AT BEGINNING OF TAPE); TIMING ERROR STATUS CLEARS "WRITE"; SDRG SDRD SOLD ISSUED AT THE WRONG TIME SETS TIMING ERROR.

9.8 CHECK UP TO SPEED CIRCUITRY TEST (SA=1400)

THIS TEST CHECKS THE UP-TO-SPEED CIRCUITRY TO FUNCTION PROPERLY WHEN CERTAIN COMMANDS ARE GIVEN TO THE DECTAPE CONTROL, THE CHECK IS PERFORMED VIA THE FEATURE OF THE UP-TO-SPEED CIRCUITRY CLEARING THE MARK TRACK REGISTER WHEN THE UP-TO-SPEED DELAY STARTS TIMING OUT, THE COMMANDS ISSUED ARE: STOP TO GO; GO TO STOP; REVERSE TO FORWARD; FORWARD TO REVERSE; UNIT 0 TO UNIT 1; UNIT 1 TO UNIT 0 (ONLY IF UNIT 1 EXISTS - SR11 SET TO 1)

9,9 ROUTINE TO SEARCH AND FIND ALL BLOCK NUMBERS (SA=2100)

THIS ROUTINE RUNS TAPE FROM ENDBONE TO ENDBONE COMPARING ALL
 BLOCK NUMBERS,

9,10 DISPLAY BLOCK NUMBER ROUTINE (SA=2200)

THIS ROUTINE RUNS TAPE FROM ENDBONE TO ENDBONE DISPLAYING
 THE CURRENT BLOCK NUMBER IN THE AC,

9,11 ROUTINE TO ROCK DECTAPE 0 (SA=2237)

THIS ROUTINE ROCKS DECTAPE 0 FOR A DISTANCE DETERMINED
 BY THE CONTENTS OF THE SWITCH REGISTER; THIS ROUTINE
 CAN BE USED TO CHECK "UP TO SPEED", SINGLE LINE FLAG,
 AND QUAD LINE FLAG LOGIC,

9,12 ROUTINE TO RUN DECTAPE FROM ENDBONE TO ENDBONE AND CHECK

THE MARK TRACK IN BLOCKS (SA=2400)

THIS ROUTINE RUNS DECTAPE 0 FROM ENDBONE TO ENDBONE AND
 CHECKS THE CONTENTS OF THE MARK TRACK ON TAPE IN THE
 BLOCKS ON TAPE,

9,13 CHECK SELECT ERROR CIRCUITRY TEST (SA=2500, 2600)

THIS TEST CHECKS THE "SELECT ERROR" CIRCUITRY OF THE
 TDBE CONTROL UNIT 0 IS "ON-LINE", UNIT 1 IS "OFF-LINE"
 OR NO-EXISTANT; FUNCTIONS CHECKED ARE: "SELECT ERROR"
 STATUS FROM UNIT 1; "SELECT ERROR" PREVENTING "WRITE"
 FROM SETTING; NO "SELECT ERROR" FROM UNIT 0,

9,14 CHECK WRITE LOCK OUT CIRCUITRY TEST (SA=2673)

THIS TEST CHECKS THE "WRITE LOCK OUT" CIRCUITRY OF THE
 TDBE CONTROL, UNIT 0 IS "ON-LINE" AND "WRITE LOCKED",
 FUNCTIONS CHECKED ARE: "WRITE-LOCK" STATUS FROM UNIT 0;
 WRITE LOCK STATUS PREVENTING "WRITE FROM SETTING,

"OK" IS PRINTED ON THE TELEPRINTER AFTER THE TWO TESTS
 DESCRIBED IN 9,14 AND 9,15 ABOVE ARE COMPLETED,

9:15

DATA TRANSFER TEST (SA=3000)

DATA TRANSFER TESTS IS A SERIES OF ROUTINES WHICH CHECK THE READ - WRITE - SEARCH CAPABILITIES OF THE T08E CONTROL; EIGHT BASIC DATA PATTERNS ARE USED FOR DATA TRANSFER, THESE ARE: A BUFFER FULL OF 0'S; A BUFFER FULL OF -1'S; A BUFFER FULL OF 2525'S; A BUFFER FULL OF THE DATA PATTERN 2225, 5522, 2535, REPEATED; A BUFFER FULL OF INCREMENT BY 1 DATA PATTERN; A BUFFER FULL OF DECREMENT BY 1 DATA PATTERN; A BUFFER FULL OF 6161'S; A BUFFER FULL OF 3434'S, DATA TRANSFERS ARE PERFORMED IN BOTH THE FORWARD AND REVERSE DIRECTION; DATA IS WRITTEN IN THE FORWARD DIRECTION, FIRST INTO BLOCK 0, THE SEQUENCE OF OPERATIONS IS: WRITE DATA IN THE FORWARD DIRECTION; READ DATA IN THE FORWARD DIRECTION; CHECK CHECKSUM AND DATA; READ DATA IN THE REVERSE DIRECTION; CHECK CHECKSUM ONLY, THIS SEQUENCE IS REPEATED EVERY 100 BLOCKS (BLOCK 0, 100, 200, 300, ETC) UP TO AND INCLUDING BLOCK 2700, IF IT IS DESIRED TO GO A DIFFERENT NUMBER OF BLOCKS FORWARD CHANGE LOCATION 3154 TO THE DESIRED NUMBER OF BLOCKS,

DATA IS THEN WRITTEN IN THE REVERSE DIRECTION, FIRST INTO BLOCK 2700, THE SEQUENCE OF OPERATIONS IS: WRITE DATA IN THE REVERSE DIRECTION; READ DATA IN REVERSE DIRECTION; CHECK CHECKSUM AND DATA; READ DATA IN THE FORWARD DIRECTION; CHECK CHECKSUM ONLY; THIS SEQUENCE IS REPEATED EVERY 100 BLOCKS (BLOCK 2700, 2600, 2500, 2400, ETC) DOWN TO AND INCLUDING BLOCK 1, IF IT IS DESIRED TO GO A DIFFERENT NUMBER OF BLOCKS REVERSE CHANGE LOCATION 3146 TO THE 2'S COMPLEMENT OF THE DESIRED NUMBER OF BLOCKS;

AFTER UNIT 0 HAS BEEN COMPLETELY TRAVERSED ONCE (FORWARD AND BACKWARD), UNIT 1 WILL BE RUN, IF AVAILABLE, THE PROGRAM WILL THEN PROCEED TO THE NEXT DATA PATTERN AND UNIT 0 AGAIN, AFTER ALL 8 DATA PATTERNS HAVE BEEN EXERCISED ON BOTH UNITS, THE PROGRAM WILL PRINT "PASS 'N' COMPLETE" ON THE TELEPRINTER, THEN PROCEED BACK TO THE FIRST DATA PATTERN,

/TDSE DIAGNOSTIC
/
/COPYRIGHT 1971
/DIGITAL EQUIP, CORP.
/MAYNARD, MASS,

/DECTAPE COMMANDS

6771 SDSS=6771 /SKIP ON SINGLE LINE FLAG
6772 SDST=6772 /SKIP ON TIMING ERROR
6773 SDSO=6773 /SKIP ON QUADRUPLE LINE FLAG
6774 SOLC=6774 /LOAD COMMAND REGISTER
6775 SLD=6775 /LOAD DATA REGISTER, CLEAR FLAGS
6776 SDRC=6776 /READ COMMAND REGISTER AND MARK TRACK, CLEAR FLAGS
6777 SDRD=6777 /READ DATA REGISTER, CLEAR FLAGS

6887 /NEW PDP-8E INSTRUCTIONS /CLEAR ALL FLAGS (GENERATE INITIALIZE)
CAF=6887

8817 =17

8817 8888 AUTO, 0
8828 8888 OUT, 0
8821 8888 IN, 0
8822 8888 CNTR1, 0
8823 8888 CNTR2, 0
8824 8888 GOOD, 0
8825 8888 HEAD1, 0
8826 8888 HEAD2, 0
8827 8888 BLK, 0
8838 8888 FILPNT, 0
/SWITCH OPTIONS:
/SR0(1) LOOP ON CURRENT SUBTEST
/SR1(1) LOOP ON CURRENT TEST
/SR2(1) LOOP ON CONTROL TESTS
/SR3(1) DON'T PRINT ERRORS
/SR4(1) DON'T HALT ON ERRORS
/SR11(1) SINGLE UNIT TRANSPORT (S-ONLY)
8831 8888 TYPE, 0
8832 8846 TFS
8833 8841 TSP
8834 8833 JMP ,=1
8835 8842 TCF
8836 7288 CLA
8837 8431 JMP I TYPE
8848 8888 CRLF, 0
8841 1177 TAD (215
8842 4831 JMS TYPE
8843 1176 TAD (212
8844 4831 JMS TYPE
8845 5448 JMP I CRLF
8846 8888 LOOP1, 0
8847 7684 LAS

8858 7884 RAL
8851 7788 SNA CLA
8852 2846 IS2 LOOP1
8853 5446 JMP I LOOP1

8854 7778 M10, -10
8855 8888 BLKTRY, 0
8856 8888 DISBL, 0
8857 8888 DISDA, 0
8868 8888 BLKCN, 0

8861 8888 BLKREV, 0
8862 1175 TAD (3888
8863 1774 TAD UNIT
8864 8774 IOT172, SOLC
8865 4773 JMS RDQUAD
8866 4773 JMS RDQUAD
8867 5461 JMP I BLKREV

8878 8888 BLKEND, 0
8871 6771 IOT173, SDSS
8872 5871 JMP ,=1
8873 6776 IOT174, SDRC
8874 8172 AND (77
8875 1171 TAD (=22
8876 7648 SZA CLA
8877 5871 JMP ,=6
8888 5478 JMP I BLKEND

8881 8888 BLKSER, 0
8882 6771 IOT175, SDSS
8883 5182 JMP ,=1
8884 6777 IOT176, SDRD
8885 3857 DCA DISDA
8886 6776 IOT177, SDRC
8887 8172 AND (77
8888 1178 TAD (=26
8889 7648 SZA CLA
8890 5182 JMP ,=10
8891 5581 JMP I BLKSER

8200 8200 PAGE
8200 5777 JMP SELECT /GO TO OPERATOR INTERVENTION TESTS FIRST
/Routine TO CHECK THE LOADING AND READING OF THE DATA REGISTER

8201 7388 DATREG, CLA CLL
8202 3828 DCA OUT /START WITH 8
8203 1376 TAD (HESS1
8204 3825 DCA HEAD1
8205 1828 TAD OUT
8206 7848 CHA
8207 8775 IOT1, SLD /LOAD DATA REGISTER WITH
8210 7288 CLA /COMPLEMENT OF DATA
8211 1828 TAD OUT

0212	6775	1072,	SOLD		/LOAD DATA REGISTER WITH DATA
0213	7200		CLA		
0214	6777	1073,	SDRD		/READ DATA REGISTER
0215	3021		DCA	IN	
0216	7604		LAS		
0217	7710		SPA	CLA	/LOOP?
0220	5210		JMP	DATREG+7	/YES
0221	1021		TAD	IN	/COMPARE DATA IN
0222	7041		CLA		
0223	1020		TAD	OUT	/WITH DATA SENT OUT
0224	7650		SNA	CLA	/EQUAL?
0225	5232		JMP	DATLUP	/YES
0226	4775		JMS	ERROR1	
0227	7604		LAS		
0230	7710		SPA	CLA	/LOOP?
0231	5210		JMP	DATREG+7	/YES
0232	2020	DATLUP,	ISE	OUT	/INCREMENT NUMBER TO BE SENT
0233	5005		JMP	DATREG+4	/GO BACK TO DO NEXT NUMBER
0234	4046		JMS	LOOP1	
0235	5201		JMP	DATREG	

/ROUTINE TO CHECK THE LOADING AND READING OF THE COMMAND REGISTER

0236	7300	CONREG,	CLA	CLL	
0237	3020		DCA	OUT	/START WITH 0
0240	1374		TAD	(MESS2	
0241	3025		DCA	HEAD1	
0242	1020		TAD	OUT	
0243	0373		AND	(6400	
0244	6774	1074,	SDLC		/LOAD COMMAND REGISTER WITH DATA
0245	7200		CLA		
0246	6776	1075,	SDRC		/READ COMMAND REGISTER
0247	0372		AND	(7400	/MASK TO C,R, BITS
0250	3021		DCA	IN	/AND STORE
0251	7604		LAS		
0252	7710		SPA	CLA	/LOOP
0253	5242		JMP	CONREG+4	/YES
0254	1020		TAD	OUT	/GET GOOD WORD
0255	0373		AND	(6400	/MASK OUT GO BIT
0256	7041		CLA		
0257	1021		TAD	IN	/COMPARE IT WITH WORD IN
0260	7650		SNA	CLA	/BITS OK?
0261	5246		JMP	CLOOP	/YES
0262	4775		JMS	ERROR1	
0263	7604		LAS		
0264	7710		SPA	CLA	
0265	5242		JMP	CONREG+4	
0266	1020	CLOOP,	TAD	OUT	
0267	1371		TAD	(400	
0270	7450		SNA		
0271	5303		JMP	INITST=2	
0272	3020		DCA	OUT	
0273	7604		LAS		
0274	7010		RAR		/MOVE SINGLE UNIT BIT INTO LINK

74 LD Command 2
RES

7300

76 RB COMMAND
PFF

75 LD Command 3

732

007 Clear
Command Reg

0275	7620	SNL	CLA		/SINGLE UNIT
0276	5242	JMP	CONREG+4		/NO
0277	7010	RAR			
0300	1020	TAD		OUT	/YES, WORKING
0301	7640	SEA	CLA	/ON 2ND UNIT?	
0302	5242	JMP	CONREG+4		/NO
0303	4046	JMS	LOOP1		
0304	5236	JMP	CONREG		
0305	7300	INITST,	CLA	CLL	/TEST INIT TO CLEAR CR
0306	1370		TAD	(MESS3	
0307	3025		DCA	HEAD1	
0310	1367		TAD	(MESS4	
0311	3026		DCA	HEAD2	
0312	1373		TAD	(6400	
0313	6774	1076,	SDLC		/LOAD CR WITH 74
0314	6007		CAF		/CLEAR CR
0315	7604		LAS		
0316	7710		SPA	CLA	/LOOP?
0317	5303		JMP	INITST	/YES
0320	6776	1077,	SDRC		/READ CR
0321	0372		AND	(7400	
0322	7650		SNA	CLA	/CR BITS 0?
0323	5330		JMP	,+3	/YES, OK
0324	4766		JMS	ERROR2	/NO, ERROR, INIT (CAF) DID NOT CLEAR CR
0325	7604		LAS		
0326	7710		SPA	CLA	/LOOP?
0327	5303		JMP	INITST	/YES
0330	4046		JMS	LOOP1	
0331	5303		JMP	INITST	
0332	3771		JMP	CHKCLA	
0366	0337				
0367	3094				
0370	3044				
0371	0400				
0372	7400				
0373	6400				
0374	3021				
0375	0476				
0376	3000				
0377	2600				
	0400				

/CHECK SDLC, SOLD, SDRC, SDRD TO CLEAR AC AT PROPER TIME (OR NOT AT ALL)

0400	7300	CHKCLA,	CLA	CLL	
0401	1377		TAD	(MESS5	
0402	3025		DCA	HEAD1	
0403	1376		TAD	(MESS6	
0404	3026		DCA	HEAD2	
0405	1167	CSOLC,	TAD	(6777	/SET AC TO 6777
0406	6774		SDLC		
0407	7650		SNA	CLA	/DID SDLC CLEAR AC (AC SHOULD CLEAR)?
0410	5215		JMP	,+3	/YES

```

0411 7604 LAS /NO,ERROR
0412 7710 SPA CLA /LOOP?
0413 5205 JMP CSOLC /NO
0414 4337 JMS ERROR2 /ERROR
0415 7604 LAS
0416 7710 SPA CLA /LOOP?
0417 5205 JMP CSOLC /YES
0420 1375 TAD (MESS7
0421 3026 DCA HEAD2
0422 7300 CSORC, CLA CLL
0423 6774 IOT9, SOLC /LOAD COMMAND REGISTER WITH B
0424 7240 CLA CMA /SET AC TO ALL 1'S
0425 6776 IOT10, SDRC /READ COMMAND REGISTER
0426 7604 SNA CLA /ALL ZERO'S (AC SHOULD CLEAR BEFORE READING)?
0427 5234 JMP ,+5 /YES
0430 7604 LAS /NO,ERROR
0431 7710 SPA CLA /LOOP?
0432 5222 JMP CSORC /YES
0433 4337 JMS ERROR2 /ERROR
0434 7604 LAS
0435 7710 SPA CLA /LOOP?
0436 5222 JMP CSORC /YES
0437 1374 TAD (MESS8
0440 3026 DCA HEAD2
0441 7240 CSOLD, CLA CMA /SET AC TO ALL 1'S
0442 6775 IOT11, SOLD /LOAD DATA REGISTER
0443 7640 SZA CLA /DID SOLD CLEAR AC (AC SHOULD NOT CLEAR)?
0444 5251 JMP ,+5 /NO, ALL OR
0445 7604 LAS /YES,ERROR
0446 7710 SPA CLA /LOOP?
0447 5241 JMP CSOLD /YES
0450 4337 JMS ERROR2 /ERROR
0451 7604 LAS
0452 7710 SPA CLA /LOOP?
0453 5241 JMP CSOLD /YES
0454 1373 TAD (MESS9
0455 3026 DCA HEAD2

0456 7300 CSORD, CLA CLL
0457 6775 IOT12, SOLD /LOAD REGISTER WITH B
0460 7240 CLA CMA /SET AC TO ALL 1'S
0461 6777 IOT13, SDRD /READ DATA REGISTER
0462 7604 SNA CLA /ALL ZERO'S(AC SHOULD CLEAR BEFORE READING)?
0463 5270 JMP ,+5 /YES
0464 7604 LAS /NO,ERROR
0465 7710 SPA CLA /LOOP?
0466 5256 JMP CSORD /YES
0467 4337 JMS ERROR2 /ERROR
0470 7604 LAS
0471 7710 SPA CLA /LOOP?
0472 5256 JMP CSORD /YES
0473 4046 JMS LOOP1
0474 5200 JMP CHKCLA
0475 5772' JMP SINGLE

```

/ERROR HANDLER ROUTINE=DATA WORD TYPEOUTS

```

0476 0000 ERROR1, 0
0477 7604 LAS /GET SR
0500 0371 AND (400 /MASK TO TYPEOUT BIT
0501 7640 SZA CLA /TYPE OUT ERROR?
0502 5325 JMP ERR1MT /NO
0503 4040 JMS CRLF /YES
0504 1025 TAD HEAD1
0505 7490 SNA /TYPE OUT HEADER?
0506 5315 JMP ,+7 /NO
0507 4770' JMS MESSAGE /YES, PRINT HEADER
0510 3025 DCA HEAD1
0511 4040 JMS CRLF /CRLF
0512 1367 TAD (FORMT1 /PRINT REST OF FORMAT
0513 4770' JMS MESSAGE
0514 4040 JMS CRLF /CRLF
0515 1020 TAD OUT /PRINT GOOD DATA
0516 0366 AND (6400
0517 4765' JMS OPRINT
0520 1344 TAD (240 /SPACE
0521 4031 JMS TYPE
0522 1021 TAD IN /PRINT BAD DATA
0523 4765' JMS OPRINT
0524 4040 JMS CRLF /CRLF
0525 7604 ERR1MT, LAS /GET SR
0526 0363 AND (200 /MASK TO HALT BIT
0527 7650 SNA CLA /STOP?
0530 7402 E1MLT, HLT /NO
0531 5676 JMP ! ERROR1 /EXIT

0532 0717 FORMT1, TEXT "GOOD BAD"
0533 1704
0534 4002
0535 0104
0536 0000

```

/ERROR HANDLER - NO DATA WORD TYPEOUTS

```

0537 0000 ERROR2, 0
0540 7604 LAS /GET SR
0541 0371 AND (400 /MASK TO TYPEOUT BIT
0542 7640 SZA CLA /TYPE OUT ERROR?
0543 5356 JMP ERR2MT /NO
0544 4040 JMS CRLF /YES
0545 1025 TAD HEAD1
0546 7490 SNA /TYPE OUT HEADER
0547 5353 JMP ,+4 /NO
0550 4770' JMS MESSAGE /YES
0551 3025 DCA HEAD1
0552 4040 JMS CRLF
0553 1026 TAD HEAD2 /TYPE OUT ERROR MESSAGE
0554 4770' JMS MESSAGE
0555 4040 JMS CRLF
0556 7604 ERR2MT, LAS /GET SR

```

```

0557 0363 AND 1200 /MASK TO HALT BIT
0560 7698 SNA CLA /STOP?
0561 7402 WLT /YES
0562 5737 JMP I ERROR2

0563 0200
0564 0240
0565 2316
0566 6400
0567 0532
0570 2264
0571 0400
0572 0600
0573 5161
0574 5191
0575 5136
0576 5123
0577 5076
0600

```

PAGE

/CHECK SINGLE LINE SKIP INSTRUCTION AND LOGIC

```

0600 7300 SINGLE, CLA CLL
0601 1377 TAD (MESS10
0602 3025 DCA HEAD1
0603 1376 TAD (MESS11
0604 3026 DCA HEAD2
0605 6774 SDLC /CLEAR ALL FLAGS INITIALLY
0606 6771 10T14, SDSS /SKIP ON SINGLE LINE
0607 7410 SKP
0610 4775 JMS ERROR2
0611 1374 TAD (1000 /ERROR, SDSS SHOULD NOT HAVE SKIPPED
0612 6774 10T15, SOLC /LOAD COMMAND REGISTER WITH US,FND,GO,READ
0613 1373 TAD (MESS12
0614 3026 DCA HEAD2

0615 7200 SINGLE, CLA
0616 1372 TAD (=1000 /SET UP FOR
0617 3022 DCA CNTR1 /A DELAY
0620 3023 DCA CNTR2 /OP ABOUT 1 SECOND
0621 6771 10T16, SDSS /SINGLE LINE FLAG UP YET?
0622 7410 SKP /NO
0623 5234 JMP SINGLE2 /YES
0624 2023 ISZ CNTR2 /NO, COUNT
0625 5221 JMP ,=4
0626 2022 ISZ CNTR1 /DELAY OVER?
0627 5221 JMP ,=6 /NO
0630 4775 JMS ERROR2 /YES, NO SINGLE LINE FLAG, OR SDSS DOES NOT SKIP
0631 7604 LAS
0632 7710 SPA CLA /LOOP?
0633 5200 JMP SINGLE /YES
0634 1371 TAD (MESS13
0635 3026 DCA HEAD2

```

```

0636 6771 SINGLE, SDSS /FLAG STILL UP?
0637 4775 JMS ERROR2 /SINGLE LINE FLAG CLEARED BY SDSS
0640 7604 LAS
0641 7710 SPA CLA /LOOP?
0642 5236 JMP SINGLE (MESS14 /YES
0643 1370 TAD (MESS14
0644 3026 DCA HEAD2
0645 6771 SINGLE, SDSS /WAIT FOR SINGLE LINE FLAG
0646 5245 JMP ,=1 /CLEAR FLAG WITH CAE
0647 6007 CAF
0650 7604 LAS /LOOP?
0651 7710 SPA CLA /YES
0652 5245 JMP SINGLE2 /DID FLAG CLEAR?
0653 6771 10T17, SDSS /YES
0654 5241 JMP SING3=4 /NO, SINGLE LINE FLAG NOT CLEARED BY CAF
0655 4775 JMS ERROR2
0656 7604 LAS /LOOP?
0657 7710 SPA CLA /YES
0660 5245 JMP SINGLE2 (1000
0661 1374 TAD (1000
0662 6774 10T18, SOLC /LOAD COMMAND REGISTER AGAIN

0663 1367 TAD (MESS15
0664 3026 DCA HEAD2
0665 6771 SINGLE, SDSS /WAIT FOR SINGLE LINE FLAG
0666 5265 JMP ,=1
0667 7200 CLA
0670 6775 10T19, SOLD /ISSUE SOLD TO CLEAR SINGLE LINE FLAG
0671 7604 LAS /LOOP?
0672 7710 SPA CLA /YES
0673 5265 JMP SING3 /FLAG STILL UP?
0674 6771 10T20, SDSS /NO
0675 5302 JMP SING4=8 ERROR2 /YES, ERROR, SINGLE LINE FLAG NOT CLEARED BY SOLD
0676 4775 JMS
0677 7604 LAS
0680 7710 SPA CLA /LOOP?
0681 5265 JMP SING3 /YES
0682 1366 TAD (MESS16
0683 3026 DCA HEAD2
0684 6771 SINGLE, SDSS /WAIT FOR SINGLE LINE FLAG
0685 5304 JMP ,=1
0686 7200 CLA
0687 6776 10T21, SDRC /ISSUE SDRC TO CLEAR SINGLE LINE FLAG
0688 7604 LAS /LOOP?
0689 7710 SPA CLA /YES
0691 5304 JMP SING4 /FLAG CLEARED?
0692 6771 10T22, SDSS /YES
0693 5321 JMP SING5=8 ERROR2 /NO, ERROR, SINGLE LINE FLAG NOT CLEARED BY SDRC
0694 4775 JMS
0695 7604 LAS /LOOP?
0696 7710 SPA CLA /YES
0697 5304 JMP SING4 (MESS17
0698 1365 TAD (MESS17
0699 3026 DCA HEAD2

```



```

0723 6771 SING5, SDSS
0724 5323 JMP
0725 7200 CLA
0726 6777 10T23, SDRD
0727 7604 LAS
0730 7710 SPA CLA
0731 5323 JMP SING5
0732 6771 10T24, SDSS
0733 5774 JMP SING6*2
0734 4775 JMS ERROR2
0735 7604 LAS
0736 7710 SPA CLA
0737 5323 JMP SING5
0740 5774 JMP SING6*2
0765 5416
0766 5373
0767 5350
0770 5326
0771 5305
0772 7000
0773 5253
0774 1000
0775 0537
0776 5222
0777 5174
1000

```

PAGE

```

1000 1377 TAD (MESS10)
1001 3026 DCA HEAD2
1002 6771 SING6, SDSS
1003 5202 JMP
1004 6772 10T25, SDST
1005 7000 NOP
1006 6773 10T26, SDSQ
1007 7200 CLA
1010 1376 TAD (1000)
1011 6774 10T27, SDLC
1012 6771 10T28, SDSS
1013 7410 SKP
1014 5221 JMP SING7
1015 4775 JMS ERROR2
1016 7604 LAS
1017 7710 SPA CLA
1020 5202 JMP SING6
1021 6774 SING7, SDLC
1022 4044 JMS LOOP1
1023 5774 JMP SINGLE

```

/CHECK QUAD LINE SKIP INSTRUCTION AND LOGIC

```

1024 7300 QUAD, CLA CLL
1025 1373 TAD (MESS19)

```

```

1026 3025 DCA HEAD1
1027 1372 TAD (MESS20)
1030 3026 DCA HEAD2
1031 6774 SDLC
1032 6773 10T29, SDSQ
1033 7410 SKP
1034 4775 JMS ERROR2
1035 1376 TAD (1000)
1036 6774 10T30, SDLC
1037 1371 TAD (MESS21)
1040 3026 DCA HEAD2
1041 6777 QUAD0, SDRD
1042 6771 10T31, SDSS
1043 9242 JMP
1044 6773 10T32, SDSQ
1045 5250 JMP
1046 4775 JMS ERROR2
1047 5274 JMP
1050 6771 10T33, SDSS
1051 7410 SKP
1052 5250 JMP
1053 6773 10T34, SDSQ
1054 5257 JMP
1055 4775 JMS ERROR2
1056 5274 JMP
1057 6771 10T35, SDSS
1060 5257 JMP
1061 6773 10T36, SDSQ
1062 5245 JMP
1063 4775 JMS ERROR2
1064 5274 JMP
1065 1370 TAD (MESS22)
1066 3026 DCA HEAD2
1067 6771 10T37, SDSS
1070 7410 SKP
1071 5207 JMP
1072 6773 10T38, SDSQ
1073 4775 JMS ERROR2
1074 7604 OBLUP, LAS
1075 7710 SPA CLA
1076 5235 JMP
1077 1367 TAD (MESS23)
1080 3026 DCA HEAD2
1081 6773 QUAD1, SDSQ
1082 4775 JMS ERROR2
1083 7604 LAS
1084 7710 SPA CLA
1085 5301 JMP QUAD1
1086 1366 TAD (MESS24)
1087 3026 DCA HEAD2
1088 6773 QUAD2, SDSQ
1089 5310 JMP
1090 6007 CAP
1091 7604 LAS

```

```

1114 7710 SPA CLA /LOOP?
1115 5310 JMP QUAD2 /YES
1116 6773 10T39, S0S0 /DID FLAG CLEAR?
1117 5324 JMP QUAD3=4 /YES
1118 4775' JMS ERROR2 /NO, QUAD LINE FLAG NOT CLEARED BY CAF
1121 7604 LAS
1122 7710 SPA CLA /LOOP?
1123 5310 JMP QUAD2 /YES
1124 1376 TAD (1000
1125 6774 10T40, SOLC /LOAD COMMAND REGISTER AGAIN
1126 1365 TAD (MESS25
1127 3026 DCA HEAD2
1130 6773 QUA03, S0S0 /WAIT FOR QUAD FLAG
1131 5330 JMP ,=I
1132 7200 CLA
1133 6775 10T41, S0LD /ISSUE S0LD TO CLEAR QUAD FLAG
1134 7604 LAS
1135 7710 SPA CLA /LOOP?
1136 5330 JMP QUAD3 /YES
1137 6773 10T42, S0S0 /FLAG STILL UP?
1140 5764' JMP QUAD4=2 /NO
1141 4775' JMS ERROR2 /YES, ERROR, QUAD FLAG NOT CLEARED BY S0LD
1142 7604 LAS
1143 7710 SPA CLA /LOOP?
1144 5330 JMP QUAD3 /YES
1145 5764' JMP QUAD4=2
1164 1200
1165 5656
1166 5635
1167 5615
1170 5564
1171 5546
1172 5516
1173 5471
1174 0600
1175 0937
1176 1000
1177 5441
1200

```

PAGE

```

1200 1377 TAD (MESS26
1201 3026 DCA HEAD2
1202 6773 QUA04, S0S0 /WAIT FOR QUAD FLAG
1203 5202 JMP ,=I
1204 7200 CLA
1205 6776 10T43, S0RC /ISSUE S0RC TO CLEAR QUAD FLAG
1206 7604 LAS
1207 7710 SPA CLA /LOOP?
1210 5202 JMP QUAD4 /YES
1211 6773 10T44, S0S0 /FLAG CLEARED?
1212 5217 JMP QUAD5=2 /YES
1213 4776' JMS ERROR2 /NO, ERROR, QUAD FLAG NOT CLEARED BY S0RC
1214 7604 LAS
1215 7710 SPA CLA /LOOP?

```

```

1216 5202 JMP QUAD4 /YES
1217 1375 TAD (MESS27
1220 3026 QUA05, DCA HEAD2
1221 6773 S0S0 /WAIT FOR QUAD FLAG
1222 5221 JMP ,=I
1223 7200 CLA
1224 6777 10T45, S0RD /ISSUE S0RD TO CLEAR QUAD LINE FLAG
1225 7604 LAS
1226 7710 SPA CLA /LOOP?
1227 5221 JMP QUAD5 /YES
1230 6773 10T46, S0S0 /FLAG CLEARED?
1231 5236 JMP QUAD6=2 /YES
1232 4776' JMS ERROR2 /NO, ERROR, QUAD FLAG NOT CLEARED BY S0RD
1233 7604 LAS
1234 7710 SPA CLA /LOOP?
1235 5221 JMP QUAD5 /YES
1236 1374 TAD (MESS28
1237 3026 DCA HEAD2
1240 6773 QUA06, S0S0 /WAIT FOR QUAD FLAG
1241 5240 JMP ,=I
1242 6772 10T47, S0ST /ISSUE S0ST
1243 7000 NOP
1244 6771 10T48, S0SS /S0SS
1245 7000 NOP
1246 7200 CLA
1247 1373 TAD (1000
1250 6774 10T49, S0LC /AND S0LC
1251 7604 LAS
1252 7710 SPA CLA /LOOP?
1253 5240 JMP QUAD6 /YES
1254 6773 10T50, S0S0 /DID STYT, S0SS, OR S0LC CLEAR FLAG?
1255 7410 SKP /YES
1256 5243 JMP QUAD7=2 /NO
1257 4776' JMS ERROR2 /ERROR, S0ST, S0SS, OR S0LC CLEARED QUAD FLAG
1260 7604 LAS
1261 7710 SPA CLA /LOOP?
1262 5240 JMP QUAD6 /YES
1263 1372 TAD (MESS29
1264 3026 DCA HEAD2
1265 7300 QUA07, CLA CLL /SET LOOP COUNT TO=2
1266 1371 TAD (=2
1267 3022 DCA CNTR1
1270 6775 10T51, S0LD /CLEAR QUAD FLAG FLIP/FLOPS
1271 6771 10T52, S0SS /WAIT FOR SINGLE LINE
1272 5271 JMP ,=I /TO COME
1273 6771 10T53, S0SS /GO AWAY
1274 7410 SKP
1275 5274 JMP ,=I
1276 6771 10T54, S0SS /AND COME AGAIN
1277 5276 JMP ,=I
1300 2022 ISB CNTR1 /TWICE THRU?
1301 5270 JMP QUAD7=3 /NO
1302 7004 LAS /YES

```

```

1303 7718 SPA CLA /LOOP?
1304 5263 JMP QUAD7 /YES
1305 6773 10T55, SDSC /NO, IS QUAD FLAG UP?
1306 7418 SKP /NO
1307 4776' JMS ERROR2 /YES, ERROR QUAD FLAG COUNTER FLIP/FLOPS NOT CLEARED
1310 7684 LAS /BY SDLC
1311 7718 SPA CLA /LOOP?
1312 5245 JMP QUAD7 /YES
1313 4846 JMS LOOP1
1314 5778' JMP QUAD

```

/CHECK TIMING ERROR SKIP INSTRUCTION AND LOGIC

```

1315 7388 TIMING, CLA CLL
1316 1367 TAD (MESS38
1317 3825 DCA HEAD1
1320 1366 TAD (MESS31
1321 3826 DCA HEAD2
1322 6774 SDLC /CLEAR ALL FLAGS INITIALLY
1323 1373 TAD (1888
1324 6774 10T56, SDLC /LOAD COMMAND REGISTER WITH U8,FWD,GO,READ
1325 6771 10T57, SDSS /WAIT FOR SINGLE
1326 5325 JMP /LINE FLAG
1327 6772 10T58, SDST =1 /SKIP ON TIMING ERROR
1330 7418 SKP
1331 4776' JMS ERROR2 /ERROR, SDST SHOULD NOT HAVE SKIPPED
1332 1365 TAD (MESS32
1333 3826 DCA HEAD2
1334 6773 TIME8, SDSC /WAIT FOR QUAD FLAG
1335 5334 JMP =1
1336 7288 CLA
1337 3822 DCA CNTR1
1340 2822 ISZ CNTR1 /WAIT A WHILE SO THAT TIMING ERROR
1341 5348 JMP =1 /CAN SET
1342 6772 10T59, SDST /TIMING ERROR SET?
1343 7418 SKP /NO
1344 5351 JMP TIME1=2 /YES
1345 4776' JMS ERROR2 /ERROR, TIMING ERROR NOT SET IN READ MODE
1346 7684 LAS
1347 7718 SPA CLA /LOOP?
1350 5334 JMP TIME8 /YES
1351 1364 TAD (MESS33
1352 3826 DCA HEAD2
1353 6772 TIME1, SDST /TIMING ERROR STILL SET?
1354 4776' JMS ERROR2 /TIMING ERROR CLEARED BY SDST
1355 7684 LAS
1356 7718 SPA CLA /LOOP?
1357 5353 JMP TIME1 /YES
1360 5763' JMP TIME2=2
1363 1488
1364 6148
1365 6181
1366 6852
1367 6826

```

```

1378 1824
1371 7776
1372 5773
1373 1888
1374 5744
1375 5722
1376 8537
1377 5788
1488

```

PAGE

```

1488 1377 TAD (MESS34
1481 3826 DCA HEAD2
1482 6772 TIME2, SDST /WAIT FOR TIMING ERROR
1483 5282 JMP =1
1484 6887 CAF /CLEAR FLAG WITH CAF
1485 7684 LAS
1486 7718 SPA CLA /LOOP?
1487 5282 JMP TIME2 /YES
1418 6772 10T60, SDST /DID FLAG CLEAR?
1411 5216 JMP TIME3=4
1412 4776' JMS ERROR2 /NO, TIMING ERROR NOT CLEARED BY CAF
1413 7684 LAS
1414 7718 SPA CLA /LOOP?
1415 5282 JMP TIME2 /YES
1416 1373 TAD (1888
1417 6774 10T61, SDLC /LOAD COMMAND REGISTER AGAIN

1420 1374 TAD (MESS35
1421 3826 DCA HEAD2
1422 6772 TIME3, SDST /WAIT FOR TIMING ERROR
1423 5222 JMP =1
1424 6776 10T62, SDRC /READ DECI/PE COMMAND REGISTER FOR STATUS
1425 3821 DCA IN /SAVE
1426 7684 LAS
1427 7718 SPA CLA /LOOP?
1430 5222 JMP TIME3 /YES
1431 1821 TAD IN /GET STATUS BACK AGAIN
1432 8373 AND (188 /MASK TO BIT 5
1433 7448 SZA /TIMING ERROR STATUS SET?
1434 5241 JMP TIME4=4 /YES, OK
1435 4776' JMS ERROR2 /NO, ERROR, TIMING ERROR STATUS NOT SET
1436 7684 LAS
1437 7718 SPA CLA /LOOP?
1440 5222 JMP TIME3 /YES
1441 1375 TAD (1888
1442 6774 10T63, SDLC /LOAD COMMAND REGISTER AGAIN
1443 1372 TAD (MESS36
1444 3826 DCA HEAD2
1445 6772 TIME4, SDST /WAIT FOR TIMING ERROR
1446 5245 JMP =1
1447 6774 10T64, SDLC /CLEAR FLAG WITH SDLC
1450 7684 LAS
1451 7718 SPA CLA /LOOP?
1452 5245 JMP TIME4 /YES

```

/TDSE DIAGNOSTIC

PAL10 V141 19OCT-72

11189 PAGE 1414

1433 6772
1454 5241
1455 4776'
1456 7684
1457 7718
1468 5243

1461 1371
1462 3826
1463 7388
1464 1378
1465 6774
1466 6771
1467 5266
1478 6776
1471 8367
1472 1366
1473 7648
1474 5266
1475 6776
1476 8365
1477 1364
1508 6774
1501 3822
1502 2822
1503 9382
1504 6772
1505 4776'
1506 1363
1507 3826
1510 6776
1511 8364
1512 7648
1513 4776'
1514 7684
1515 7718
1516 5263

10T65, SDST
JMP TIME3=2
JMS ERROR2
LAS
SPA CLA
JMP TIME4

TAD (MESS37
DCA HEAD2
TIME5, CLA CLL (3888
TAD
10T66, SDLC
10T67, SDSS
JMP =1
10T68, SDRC
AND (77
TAD (=22
SEA CLA
JMP =6
10T69, SDRC (7888
AND (488
TAD
10T70, SDLC
DCA CNTR1
ISE CNTR1
JMP =1
10T71, SDST
JMS ERROR2 (MESS38
TAD HEAD2
DCA
10T72, SDRC (488
AND
SEA CLA
JMS ERROR2
LAS
SPA CLA
JMP TIME5

/DID FLAG CLEAR?
/YES
/NO, TIMING ERROR NOT CLEARED BY SOLC
/LOOP?

/GET TAPE MOVING BACKWARD
/WAIT FOR END ZONE

/SET "WRITE"

/WAIT A WHILE
/TIMING ERROR?
/NO, ERROR

/YES, READ STATUS
/"WRITE" CLEARED
/NO, ERROR
/LOOP?
/YES

1517 1362
1520 3826
1521 7388
1522 1375
1523 6774
1524 6771
1525 9324
1526 1361
1527 3823
1530 3822
1531 6776
1532 6777
1533 6775
1534 2822
1535 9331

TAD (MESS39
DCA HEAD2
TIME6, CLA CLL (1888
TAD
10T73, SDLC
10T74, SDSS
JMP =1
TAD (=8
DCA CNTR2
DCA CNTR1
10T75, SDRC
10T76, SDRD
10T77, SDLD
ISE CNTR1
JMP =6

/SET UNIT 8 RUNNING FORWARD
/WAIT FOR "UP TO SPEED"

/ISSUE MANY SDRD, SDRD, SOLC'S

/TDSE DIAGNOSTIC

PAL10 V141 19OCT-72

11189 PAGE 1415

1536 2823
1537 9331
1540 7684
1541 7718
1542 5327
1543 6772
1544 4776'
1545 7684
1546 7718
1547 5321
1550 4848
1551 5768'
1552 5757'
1557 1688
1560 1315
1561 7773
1562 6324
1563 6276
1564 8488
1565 7888
1566 7756
1567 8877
1570 3888
1571 6252
1572 6231
1573 8188
1574 6177
1575 1888
1576 8537
1577 6157
1688

ISE CNTR2
JMP =6
LAS
SPA CLA
JMP TIME4+6
10T78, SDST
JMS ERROR2
LAS
SPA CLA
JMP TIME6
JMS LOOP1
JMP TIMING
JMP UTSHRK

/LOOP?
/YES
/TIMING ERROR?
/NO, ERROR
/LOOP?
/YES

PAGE

/CHECK UP TO SPEED CIRCUITRY TO CLEAR MARK TRACK WINDOW

1600 7388
1601 1377
1602 3823
1603 1376
1604 3826
1605 6774
1606 1375
1607 6774
1610 7684
1611 7718
1612 5288
1613 6776
1614 8374
1615 7448
1616 4773'
1617 7684
1620 7718
1621 5288

UTSHRK, CLA CLL
TAD (MESS43
DCA HEAD1
TAD (MESS44
DCA HEAD2
10T82, SDLC
TAD (1888
10T83, SDLC
LAS
SPA CLA
JMP UTSHRK
10T84, SDRC
AND (77
SEA
JMS ERROR2
LAS
SPA CLA
JMP UTSHRK

/CLEAR STOP/GO BIT

/SET STOP/GO BIT

/LOOP?
/YES
/READ MARK TRACK
/ZERO?
/NO, ERROR
/LOOP?
/YES

```

1622 1372          TAD      (MESS45
1623 3826          DCA      HEAD2
1624 7388          UTSMK1, CLA CLL
1625 1375          TAD      (1888          /SET STOP/80 BIT,
1626 6774          IOT85,  SDLC
1627 6771          IOT86,  SDSS          /SINGLE LINE FLAG?
1630 5227          JMP      ,=1          /NO
1631 6776          IOT87,  SORC          /YES, READ MARK TRACK
1632 8374          AND      (77
1633 7658          SNA CLA
1634 5227          JMP      ,=5          /ZERO?
1635 6774          IOT88,  SDLC          /YES, TRY AGAIN
1636 7684          LAS
1637 7718          SPA CLA          /LOOP?
1640 5224          JMP      UTSMK1          /YES
1641 6776          IOT89,  SORC          /READ MARK TRACK
1642 8374          AND      (77
1643 7448          SEA
1644 4773          JMS      ERROR2          /ZERO?
1645 7684          LAS          /NO, ERROR
1646 7718          SPA CLA          /LOOP?
1647 5224          JMP      UTSMK1          /YES
1650 1371          TAD      (MESS46
1651 3826          DCA      HEAD2
1652 7388          UTSMK2, CLA CLL
1653 1378          TAD      (3888          /SET STOP/80 AND PWD/REV
1654 6774          IOT90,  SDLC
1655 6771          IOT91,  SDSS
1656 5255          JMP      ,=1
1657 6776          IOT92,  SORC
1658 8374          AND      (77
1659 7658          SNA CLA
1662 5255          JMP      ,=5          /CLEAR PWD/REV (BIT1)
1663 1375          IOT93,  TAD      (1888
1664 6774          SDLC
1665 7684          LAS
1666 7718          SPA CLA          UTSMK2
1667 5252          JMP      UTSMK2
1670 6776          IOT94,  SORC
1671 8374          AND      (77
1672 7448          SEA          /MARK TRACK ZERO?
1673 4773          JMS      ERROR2          /NO, ERROR
1674 7684          LAS
1675 7718          SPA CLA
1676 5252          JMP      UTSMK2

1677 1367          TAD      (MESS47
1780 3826          DCA      HEAD2
1781 7388          UTSMK3, CLA CLL
1782 1375          TAD      (1888          /SET STOP/80, CLEAR PWD/REV (BIT1)
1783 6774          IOT95,  SDLC
1784 6771          IOT96,  SDSS
1785 5384          JMP      ,=1
1786 6776          IOT97,  SORC
    
```

```

1787 8374          AND      (77
1718 7658          SNA CLA
1711 5384          JMP      ,=5
1712 1378          TAD      (3888          /SET PWD/REV (BIT 1)
1713 6774          IOT98,  SDLC
1714 7684          LAS
1715 7718          SPA CLA
1716 5381          JMP      UTSMK3
1717 6776          IOT99,  SORC
1720 8374          AND      (77
1721 7448          SEA          /MARK TRACK ZERO?
1722 4773          JMS      ERROR2          /NO, ERROR
1723 7684          LAS
1724 7718          SPA CLA
1725 5381          JMP      UTSMK3
1726 5766          JMP      UTSMK4=2
1766 2888
1767 6517
1770 3888
1771 6466
1772 6441
1773 8537
1774 8877
1775 1888
1776 6415
1777 6352

          PAGE

2888 1377          TAD      (MESS48
2881 3826          DCA      HEAD2
2882 7388          UTSMK4, CLA CLL
2883 1376          TAD      (1888          /SET STOP/80, CLEAR UNIT (BIT8)
2884 6774          IOT100, SDLC
2885 6771          IOT101, SDSS
2886 5205          JMP      ,=1
2887 6776          IOT102, SORC
2810 8375          AND      (77
2811 7698          SNA CLA
2812 5205          JMP      ,=5          /SET UNIT (BIT8)
2813 1374          IOT103, TAD      (5888
2814 6774          SDLC
2815 7684          LAS
2816 7718          SPA CLA          UTSMK4
2817 5202          JMP      UTSMK4
2820 6776          IOT104, SORC
2821 8375          AND      (77
2822 7448          SEA          /MARK TRACK 8?
2823 4773          JMS      ERROR2          /NO
2824 7684          LAS
2825 7718          SPA CLA
2826 5202          JMP      UTSMK4
2827 7684          LAS
2830 7818          RAR
2831 7638          SEL CLA          /IS THERE A UNIT?
    
```

2832 9262

JMP

UTSHK6

/NO

2833 1372
 2834 3826
 2835 7388
 2836 1374
 2837 6774
 2848 6771
 2841 9248
 2842 6776
 2843 8375
 2844 7658
 2845 9248
 2846 1376
 2847 6774
 2858 7684
 2851 7718
 2852 5235
 2853 6776
 2854 8375
 2855 7448
 2856 4773'
 2857 7684
 2868 7718
 2861 9235
 2862 4846
 2863 9771'
 2864 1378
 2865 6774
 2866 7684
 2867 7886
 2878 7718
 2871 5767'
 2872 5766'

UTSHK5,
 10T105,
 10T106,
 10T107,
 10T108,
 10T109,
 UTSHK6,
 10T110,
 2100
 BLKCH,
 10T171,
 FBLKCT,

TAD (MESS49
 DCA HEAD2
 CLA CLL
 TAD (5888
 SOLC
 SDSS
 JMP =4
 SDRC (77
 AND
 SNA CLA
 JMP =5
 TAD (1888
 SOLC
 LAS
 SPA CLA
 JMP UTSHK5
 SDRC (77
 AND
 SEA
 JMS ERROR2
 LAS
 SPA CLA
 JMP UTSHK5
 JMS LOOP1
 JMP UTSHRK
 TAD (4888
 SOLC
 LAS
 RTL
 SPA CLA
 JMP DAYREC
 XFER

/SET STOP/GO, UNIT (BIT8)
 /CLEAR UNIT (BIT2)
 /MARK TRACK ZERO?
 /NO, ERROR
 /STOP UNIT 1 IF MOVING
 /ROUTINE TO SEARCH AND FIND ALL BLOCK NUMBERS
 /THE RIGHT HAND REEL MUST HAVE AT LEAST FOUR TURNS OF TAPE ON IT

2100 7300
 2101 3856
 2102 1166
 2103 3868
 2104 4861
 2105 4878
 2106 1165
 2107 1769'
 2118 6774
 2111 4764'
 2112 4764'
 2113 4181
 2114 1857
 2115 7841
 2116 1856
 2117 7648
 2128 5346

CLA CLL
 DCA DISBL
 TAD (=8782
 DCA BLKCN
 JMS BLKREV
 JMS BLKEND
 TAD (1888
 TAD UNIT
 SOLC
 JMS RDGUAD
 JMS RDGUAD
 JMS BLKSER
 TAD DISDA
 CIA
 TAD DISBL
 SEA CLA
 JMP BLKERR

/BLOCKS DIDN'T COMPARE

2121 2856
 2122 2868
 2123 5313
 2124 4878
 2125 1166
 2126 3856
 2127 1166
 2128 3868
 2131 4861
 2132 4181
 2133 1857
 2134 7841
 2135 1856
 2136 7648
 2137 5346
 2148 7848
 2141 1856
 2142 3856
 2143 2868
 2144 5332
 2145 5388
 2146 7388
 2147 1856
 2158 7482
 2151 7288
 2152 1857
 2153 7482
 2154 9388
 2164 4787
 2165 2234
 2166 3888
 2167 8281
 2178 4888
 2171 1688
 2172 6684
 2173 8537
 2174 9888
 2175 8877
 2176 1888
 2177 4558
 2288 2288

ISE
 JMS
 TAD
 DCA
 TAD
 DCA
 JMS
 JMS
 TAD
 CIA
 TAD
 SEA
 JMP
 CMA
 TAD
 DCA
 ISE
 JMP
 JMP
 BLKERR,
 RBLKCT,
 RBLKCT,
 JMP

DISBL
 BLKCN
 FBLKCT
 BLKEND
 (=2781
 DISBL
 (=8782
 BLKCN
 BLKREV
 BLKSER
 DISDA
 DISBL
 CLA
 BLKERR
 DISBL
 DISBL
 BLKCN
 RBLKCT
 BLKCH
 CLL
 DISBL
 DISDA
 BLKCH

/AC=THE BLOCK NUMBER THAT WAS BEING SEARCHED FOR
 /AC=THE BLOCK NUMBER THAT WAS FOUND
 /RETURN TO START OF ROUTINE

PAGE

/TAPE 2
 /ROUTINE TO RUN FROM END ZONE TO END ZONE
 /AND DISPLAY THE CURRENT BLOCK NUMBER IN THE AC

2288 7388
 2281 3233
 2282 1377
 2283 1234
 2284 6774

DBLOCK,
 10T111,

CLA CLL
 DCA
 TAD
 TAD
 SOLC

DISBLK
 (3888
 UNIT
 /LOAD CONTROL WITH UNIT REV GO READ

```

2205 7300
2206 6771 DISLUP, SDRS /WAIT FOR SINGLE LINE FLAG
2207 5286 JMP ,=1
2210 7300 CLA CLL
2211 6777 IOT112, SDRD /READ DATA BUFFER
2212 3236 DCA DISDAT /AND SAVE
2213 6776 IOT113, SDRC /READ MARK TRACK
2214 8376 AND (77
2215 1375 TAD (=26
2216 7448 SEA /BLOCK NUMBER?
2217 5224 JMP DISEND /NO, CHECK FOR END ZONE
2220 1236 TAD DISDAT /YES, DISPLAY BLOCK NUMBER
2221 2233 ISE DISBLK
2222 5221 JMP ,=1
2223 5286 JMP DISLUP
2224 1374 DISEND, TAD (4
2225 7648 SEA CLA /END ZONE?
2226 5286 JMP DISLUP /NO, LOOP
2227 6776 IOT114, SDRC /YES, EXTRACT DIRECTION BIT
2230 7806 RTL /AND COMPLEMENT
2231 7832 CML RTR
2232 5284 JMP DISLUP=2 /GO LOAD INTO CONTROL
2233 8888 DISBLK, 0
2234 8888 UNIT, 0
2235 8888 DISTRK, 0
2236 8888 DISDAT, 0
/ROUTINE TO ROCK DECTAPE UNIT 0
/FOR A DISTANCE DETERMINED BY ACS

2237 7300 ROCK, CLA CLL
2240 1373 TAD (1000
2241 6774 IOT115, SOLC
2242 7684 LAS
2243 7848 CMA
2244 3881 DCA 1
2245 2888 ISE 0
2246 5245 JMP ,=1
2247 2881 ISE 1
2248 5245 JMP ,=3
2251 7888 NOP
2252 1377 TAD (3000
2253 6774 IOT116, SOLC
2254 7684 LAS
2255 7848 CMA
2256 3881 DCA 1
2257 2888 ISE 0
2260 5257 JMP ,=1
2261 2881 ISE 1
2262 5257 JMP ,=3
2263 5248 JMP ROCK+1
2264 8888 MESSAGE, 0
2265 3315 DCA MPNTR
2266 1715 TAD I MPNTR
2267 7812 RTR
2270 7812 RTR

```

```

2271 7812 RTR
2272 8376 AND (77
2273 7458 SNA
2274 5664 JMP I MESSAGE
2275 1372 TAD (=40
2276 7518 SPA
2277 1371 TAD (100
2300 1370 TAD (240
2301 4831 JMS TYPE
2302 1715 TAD I MPNTR
2303 8376 AND (77
2304 7458 SNA
2305 5664 JMP I MESSAGE
2306 1372 TAD (=40
2307 7518 SPA
2310 1371 TAD (100
2311 1370 TAD (240
2312 4831 JMS TYPE
2313 2315 ISE MPNTR
2314 5266 JMP MESSAGE+2
2315 8888 MPNTR, 0
2316 8888 OPRINT, 0
2317 3348 DCA ONUMB
2320 1367 TAD (=4
2321 3341 DCA OCNT
2322 1348 TAD ONUMB
2323 7884 RAL
2324 7884 OPLOOP, RAL
2325 7884 RTL
2326 3348 DCA ONUMB
2327 1348 TAD ONUMB
2330 8366 AND (7
2331 1365 TAD (=268
2332 4831 JMS TYPE
2333 1348 TAD ONUMB
2334 2341 ISE OCNT
2335 5324 JMP OPLOOP
2336 7288 CLA
2337 5716 JMP I OPRINT
2340 8888 ONUMB, 0
2341 8888 OCNT, 0
2365 8268
2366 8887
2367 7774
2370 8248
2371 8188
2372 7748
2373 1888
2374 8884
2375 7752
2376 8877
2377 3888
2488

```

PAGE

2400	7300	BLKCHK, CLA CLL		
2401	1377	TAD	(3000)	/START TAPE MOVING BACKWARD
2402	6774	10T117, SDLC		
2403	4315	JMS	RD6HRK	/WAIT FOR WINDOW TO OPEN
2404	4307	END2, JMS	RD1HRK	/READ BACK MARK TRACK
2405	1374	TAD	(=22)	
2406	7640	SEA CLA		/ENDZONE?
2407	9204	JMP	,=3	/NO
2410	6776	10T118, SDRC		/TURN AROUND
2411	7006	RTL		
2412	7832	CML RTR		
2413	6774	10T119, SDLC		
2414	4315	JMS	RD6HRK	/WAIT FOR WINDOW TO OPEN
2415	4307	JMS	RD1HRK	/READ MARK TRACK
2416	1375	TAD	(=26)	
2417	7650	SNA CLA		/BLOCK NUMBER?
2420	9236	JMP	RVGARD	/YES, GO CHECK REVERSE GUARD
2421	9215	JMP	,=4	/NO, LOOK AGAIN
2422	4315	FNDEXP, JMS	RD6HRK	/READ MARK TRACK
2423	1374	TAD	(=25)	
2424	7440	SEA		/EXPAND CODE?
2425	7402	HLT		/NO, ERROR
2426	4315	BLKHRK, JMS	RD6HRK	/READ MARK TRACK
2427	1375	TAD	(=26)	
2430	7450	SNA		/BLOCK NUMBER?
2431	9236	JMP	RVGARD	/YES, GO CHECK REVERSE GUARD
2432	7001	IAC		/NO
2433	7440	SEA		/EXPAND CODE?
2434	7402	HLT		/NO, UNKNOWN
2435	9204	JMP	END2	/YES, EXPAND CODE, GO LOOK FOR ENDZONE
2436	4315	RVGARD, JMS	RD6HRK	/GET MARK TRACK
2437	1373	TAD	(=32)	
2440	7440	SEA		/REVERSE GUARD?
2441	7402	HLT		/NO, ERROR
2442	1372	TAD	(=4)	/SET UP
2443	3000	DCA	B	/FOR 4 MARKS
2444	4315	JMS	RD6HRK	/GET MARK TRACK
2445	1371	LOCK, TAD	(=10)	
2446	7440	SEA		/LOCK, REV CHKSM, REV FINAL, REV PRE=FINAL?
2447	7402	HLT		/NO, ERROR
2450	2000	ISE	B	
2451	9244	JMP	,=5	
2452	1370	DATA, TAD	(=122)	/SET UP
2453	3000	DCA	B	/FOR 82 MARKS
2454	4315	JMS	RD6HRK	/GET MARK TRACK
2455	1367	TAD	(=70)	
2456	7440	SEA		/DATA MARK?
2457	7402	HLT		/NO, ERROR
2460	2000	ISE	B	
2461	9254	JMP	,=5	
2462	1372	PREFIN, TAD	(=4)	/SET UP
2463	3000	DCA	B	/FOR 4 MARKS
2464	4315	JMS	RD6HRK	/GET MARK TRACK
2465	1366	TAD	(=73)	
2466	7440	SEA		/PREFINAL, FINAL, CHKSM, REVLOCK?

2467	7402	HLT		/NO, ERROR
2470	2000	ISE	B	
2471	9204	JMP	,=5	
2472	4315	GUARD, JMS	RD6HRK	/GET MARK TRACK
2473	1360	TAD	(=51)	
2474	7440	SEA		/GUARD?
2475	7402	HLT		/NO, ERROR
2476	4315	REVBK, JMS	RD6HRK	/GET MARK TRACK
2477	1364	TAD	(=40)	
2500	7440	SEA		/REVERSE BLOCK NUMBER?
2501	7402	HLT		/NO, ERROR
2502	4315	REVEXP, JMS	RD6HRK	/GET MARK TRACK
2503	1374	TAD	(=25)	
2504	7440	SEA		/REVERSE EXPAND CODE?
2505	7402	HLT		/NO, ERROR
2506	9222	JMP	FNDEXP	
2507	0000	/READ 1 SHIFT OF MARK TRACK SUBROUTINE		
2510	6771	RD1HRK, B		
2511	9310	10T120, SOSS		
2512	6776	JMP	,=1	
2513	0363	10T121, SDRC		
2514	9707	AND	(77)	
		JMP 1	RD1HRK	
2515	0000	/READ 0 SHIFTS OF MARK TRACK SUBROUTINE		
2516	1362	RD6HRK, B		
2517	3307	TAD	(=6)	
2520	6771	10T122, SOSS		
2521	9320	JMP	,=1	
2522	6776	10T123, SDRC		
2523	2307	ISE	RD1HRK	
2524	9320	JMP	,=4	
2525	0363	AND	(77)	
2526	9715	JMP 1	RD6HRK	
2502	7772			
2503	0077			
2504	7733			
2505	7727			
2506	7705			
2507	7710			
2508	7656			
2509	7770			
2510	7774			
2511	7746			
2512	7753			
2513	7792			
2514	7756			
2515	3000			
2516	2000			

PAGE

/CHECK SELECT ERROR STATUS BIT AND ABILITY TO CLEAR "WRITE"
 /UNIT 1 IS "OFF-LINE" OR NON-EXISTANT
 /UNIT 0 IS "ON LINE" AND "WRITE LOCKED"
 SELECT, CLA CLL


```

2601 1377 TAD (MESS50
2602 3025 DCA HEAD1
2603 1376 TAD (MESS51
2604 3026 DCA HEAD2
2605 6774 10T124, SDLC
2606 6772 10T125, SDST /IS TIMING ERROR SET?
2607 7410 SKP
2610 4775 JMS ERROR2 /YES, ERROR
2611 1374 TAD (MESS52
2612 3026 DCA HEAD2
2613 1373 TAD (4000
2614 6774 10T126, SDLC /SET UNIT BIT TO 1
2615 7200 CLA
2616 6776 10T127, SDRC /READ STATUS
2617 3021 DCA IN /SAVE
2620 7604 LAS
2621 7710 SPA CLA /LOOP?
2622 5200 JMP SELECT /YES
2623 1021 TAD IN
2624 0372 AND (100
2625 7650 SNA CLA /SELECT ERROR?
2626 4775 JMS ERROR2 /NO, ERROR
2627 7604 LAS
2630 7710 SPA CLA /LOOP?
2631 5200 JMP SELECT /YES
2632 1371 TAD (MESS53
2633 3026 DCA HEAD2
2634 1370 SELECT1, TAD (4000
2635 6774 10T128, SDLC /TRY TO SET "WRITE"
2636 7604 LAS
2637 7710 SPA CLA /LOOP?
2640 5234 JMP SELECT1 /YES
2641 6776 10T129, SDRC /READ STATUS
2642 3021 DCA IN /SAVE
2643 1021 TAD IN
2644 0367 AND (400
2645 7640 SEA CLA /WRITE SET?
2646 4775 JMS ERROR2 /YES, ERROR
2647 7604 LAS
2650 7710 SPA CLA /LOOP?
2651 5234 JMP SELECT1 /YES
2652 1366 TAD (MESS63
2653 3026 DCA HEAD2
2654 6774 SELECT2, SDLC /SELECT UNIT B
2655 7604 LAS
2656 7710 SPA CLA /LOOP?
2657 5234 JMP SELECT2 /YES
2660 6776 10T130, SDRC /READ STATUS
2661 3021 DCA IN /SAVE
2662 1021 TAD IN
2663 0372 AND (100
2664 7640 SEA CLA /SELECT ERROR?
2665 4775 JMS ERROR2 /YES
2666 7604 LAS
2667 7710 SPA CLA /LOOP?

```

```

2670 5234 JMP SELECT2 /YES
2671 4046 JMS LOOP1
2672 5200 JMP SELECT
/CHECK WRITE LOCK OUT STATUS BIT AND ABILITY TO CLEAR "WRITE"
/UNIT B IS "WRITE=LOCKED"
2673 7300 WL0, CLA CLL
2674 1365 TAD (MESS54
2675 3025 DCA HEAD1
2676 1364 TAD (MESS55
2677 3026 DCA HEAD2
2680 6774 10T131, SDLC
2681 6776 SDRC /READ STATUS
2682 3021 DCA IN /SAVE
2683 7604 LAS
2684 7710 SPA CLA /LOOP?
2685 5273 JMP WL0 /YES
2686 1021 TAD IN
2687 0363 AND (200
2690 7650 SNA CLA /WRITE LOCK OUT BIT SET?
2691 4775 JMS ERROR2 /NO, ERROR
2692 7604 LAS
2693 7710 SPA CLA /LOOP?
2694 5273 JMP WL0 /YES
2695 1362 TAD (MESS56
2696 3026 DCA HEAD2
2697 1367 WL1, TAD (400
2698 6774 10T132, SDLC /TRY TO SET "WRITE"
2699 7604 LAS
2700 7710 SPA CLA /LOOP?
2701 5317 JMP WL1 /YES
2702 6776 10T133, SDRC /READ STATUS
2703 3021 DCA IN /SAVE
2704 1021 TAD IN
2705 0367 AND (400
2706 7640 SEA CLA /WRITE SET?
2707 4775 JMS ERROR2 /YES, ERROR
2708 7604 LAS
2709 7710 SPA CLA /LOOP?
2710 5317 JMP WL1 /YES
2711 4046 JMS LOOP1
2712 5273 JMP WL2
2713 1361 TAD (OK
2714 4760 JMS MESSAGE
2715 4040 JMS CRLF
2716 402 MLT
2717 5342 JMP
2718 1713 OK, TEXT "OK"
2719 8000
2720 2264
2721 2744
2722 6767
2723 0200
2724 6744
2725 6730

```

2764 7107
 2767 8409
 2770 4409
 2771 6706
 2772 0108
 2773 4808
 2774 6664
 2775 8537
 2776 6693
 2777 6648
 3888

PAGE

/TDBE READ-WRITE AND SEARCH TEST PROGRAM
 /COPYRIGHT 1971, DIGITAL EQUIPMENT CORP., MAYNARD, MASS, 01754

7200
 7400

BUFF1=7200
 BUFF2=7400

/ROUTINE TO CHECK DATA TRANSFERS ON TAPE

```

3888 7308 XFER, CLA CLL
3881 3821 DCA IN
3882 1377 TAO (FILL8
3883 4224 JMS WREAD /FILL A BUFFER, THEN WRITE AND READ 0'S
3884 1376 TAO (FILL1
3885 4224 JMS WREAD /FILL A BUFFER, THEN WRITE AND READ 1'S
3886 1375 TAO (FILL25
3887 4224 JMS WREAD /FILL A BUFFER, THEN WRITE AND READ 2525
3888 1374 TAO (FILPAT
3889 4224 JMS WREAD /FILL A BUFFER, THEN WRITE AND READ 2225,
/5522,2555
/INCREMENT PATTERN
3882 1373 TAO (FILING
3883 4224 JMS WREAD /INCREMENT PATTERN
3884 1372 TAO (FILDEC
3885 4224 JMS WREAD /DECREMENT PATTERN
3886 1371 TAO (SPEC1
3887 4224 JMS WREAD /6161
3888 1370 TAO (SPEC2
3889 4224 JMS WREAD /3434
3890 4747 JMS PARCNT
3891 5282 JMP XFER=2

/ROUTINE TO WRITE AND READ BACK AND COMPARE EVERY 160TH BLOCK ON TAPE
WREAD, B
3824 8888 DCA FILPNT
3825 3830 DCA BUNIT
3826 3766 TAO (=888
3827 1365 JMS I FILPNT /FILL BUFF1 WITH DATA
3828 4438 JMS I FILPNT
3829 7200 BUFF1
3830 3827 DCA BLK /ZERO BLOCK NUMBER
3831 7200 DCA (MESS59
3832 1364 TAO HEAD1
3833 3825 WRL1, TAO (MESS60
3834 3826 DCA HEAD2
3835 1363 TAO HEAD1
3836 3826 DCA HEAD2
3837 1827 TAO BLK
  
```

3848 4762 JMS WRITE
 3841 7200 BUFF1
 3842 7608 =200
 3843 1361 TAO (MESS59
 3844 3826 DCA HEAD2
 3845 1827 TAO BLK
 3846 4760 JMS READ /READ BACK INTO MEMORY
 3847 7400 BUFF2
 3848 7577 =201
 3849 1365 TAO (=200
 3850 4797 JMS COMPAR /COMPARE DATA
 3851 7200 BUFF1
 3852 7401 BUFF2=1
 3853 1364 TAO (MESS60
 3854 3826 DCA HEAD2
 3855 1827 TAO BLK
 3856 4795 JMS READR /READ BACK BACKWARDS
 3857 7400 BUFF2
 3858 7577 =201
 3859 1827 TAO BLK /BUMP BLOCK NUMBER
 3860 1364 TAO (=100
 3861 3827 DCA BLK
 3862 1827 TAO BLK
 3863 1363 TAO (=2701
 3864 7710 SPA CLA
 3865 5235 JMP WRL1
 3866 1362 TAO (2701
 3867 3827 DCA BLK /SET BLOCK NUMBER TO 2701
 3868 1361 TAO (MESS61
 3869 3825 DCA HEAD1
 3870 1360 WRL2, TAO (MESS62
 3871 3826 DCA HEAD2
 3872 1827 TAO BLK
 3873 4747 JMS WRITER /WRITE ONTO TAPE BACKWARDS
 3874 7200 BUFF1
 3875 7400 =200
 3876 1364 TAO (MESS60
 3877 3826 DCA HEAD2
 3878 1827 TAO BLK
 3879 4740 JMS READR /READ BACK INTO MEMORY BACKWARDS
 3880 7400 BUFF2
 3881 7577 =201
 3882 1365 TAO (=200
 3883 4797 JMS COMPAR /COMPARE DATA
 3884 7200 BUFF1
 3885 7401 BUFF2=1
 3886 1361 TAO (MESS59
 3887 3826 DCA HEAD2
 3888 1827 TAO BLK
 3889 4740 JMS READ /READ BACK FORWARD
 3890 7400 BUFF2
 3891 7577 =201
 3892 1827 TAO BLK /BUMP BLOCK NUMBER
 3893 1364 TAO (=100

3126 3027
 3127 1027
 3130 7700
 3131 5276
 3132 7604
 3133 7010
 3134 7630
 3135 5024
 3136 1766
 3137 1345
 3140 7430
 3141 5024
 3142 3766
 3143 5232
 3145 4000
 3146 7700
 3147 3671
 3150 7075
 3151 7042
 3150 2701
 3153 7077
 3154 0100
 3155 3714
 3156 7070
 3157 3200
 3160 4600
 3161 7037
 3162 4472
 3163 7025
 3164 7012
 3165 7000
 3166 4471
 3167 3477
 3170 3461
 3171 3443
 3172 3421
 3173 3400
 3174 3276
 3175 3260
 3176 3243
 3177 3227
 3200

DCA BLK
 TAD BLK
 SNA CLA
 JMP WRRL2
 LAB
 RAR
 SEL CLA
 JMP I WREAD
 TAD SUNIT
 TAD (4000
 SNA
 JMP I WREAD
 DCA SUNIT
 JMP WRRL103

/TWO UNITS?
 /NO
 /YES, INCREMENT
 /UNIT
 /EXIT IF BACK TO ZERO
 /STORE BACK IF NO=ZERO
 /LOOP

PAGE

/SUBROUTINE TO COMPARE TWO DATA BUFFERS, INDICATE AN ERROR
 /CALLING SEQUENCE:
 / TAD (=-N /MINUS (2'S) NUMBER OF WORDS TO COMPARE
 / JMS COMPAR /CALL SUBROUTINE
 / ADDR /1ST ADDRESS OF GOOD DATA
 / TADD /1ST ADDRESS OF TEST DATA
 / RETURN HERE WHEN DONE

3200 0000
 3201 3224
 3202 1600

COMPAR, 0
 DCA CCNTR
 TAD I COMPAR

3203 3225
 3204 2200
 3205 1600
 3206 3226
 3207 2200
 3210 1377
 3211 3776
 3212 1625
 3213 7041
 3214 1626
 3215 7640
 3216 4775
 3217 2225
 3220 2220
 3221 2224
 3222 5212
 3223 5000
 3224 0000
 3225 0000
 3226 0000

DCA GPNTR
 ISZ COMPAR
 TAD I COMPAR
 DCA TPNTR
 ISZ COMPAR
 TAD (DATHE
 DCA DATHD
 CONLUP, TAD I GPNTR
 CIA
 TAD I TPNTR
 SZA CLA
 JMS DATERR
 ISZ GPNTR
 ISZ TPNTR
 ISZ CCNTR
 JMP CONLUP
 JMP I COMPAR
 CCNTR, 0
 GPNTR, 0
 TPNTR, 0

/SUBROUTINE TO FILL MEMORY WITH ZEROS
 /CALLING SEQUENCE:
 / TAD (=-N /MINUS (2'S) NUMBER OF WORDS TO FILL
 / JMS FILL0 /CALL SUBROUTINE
 / ADDR /1ST ADDRESS TO FILL

3227 0000
 3230 3241
 3231 1627
 3232 3242
 3233 2227
 3234 3642
 3235 2242
 3236 2241
 3237 5234
 3240 5627
 3241 0000
 3242 0000

FILL0, 0
 DCA FILL0C
 TAD I FILL0
 DCA FILL0P
 ISZ FILL0
 DCA I FILL0P
 ISZ FILL0P
 ISZ FILL0C
 JMP I=5
 JMP I FILL0

/SUBROUTINE TO FILL MEMORY WITH 01 (7777)
 /CALLING SEQUENCE:
 / TAD (=-N /MINUS (2'S) NUMBER OF WORDS TO FILL
 / JMS FILL1 /CALL SUBROUTINE
 / ADDR /1ST ADDRESS TO FILL

3243 0000
 3244 3296
 3245 1643
 3246 3297
 3247 2243
 3250 7240
 3251 3657
 3252 2297

FILL1, 0
 DCA FILL1C
 TAD I FILL1
 DCA FILL1P
 ISZ FILL1
 ISZ FILL1C
 CLA CMA
 DCA I FILL1P
 ISZ FILL1P

```

3293 2296      ISE  FILL1C
3294 2298      JMP  ,=4
3295 5443      JMP I  FILL1
3296 0000      FILL1C, 0
3297 0000      FILL1P, 0
/SUBROUTINE TO FILL MEMORY WITH 2525
/CALLING SEQUENCE)
/      TAD  (=N          /MINUS (219) NUMBER OF WORDS TO FILL
/      JMS  FILL25      /CALL SUBROUTINE
/      ADDR          /1ST ADDRESS TO FILL

3260 0000      FILL25, 0
3261 3273      DCA  FILL2C
3262 1040      TAD I  FILL25
3263 3275      DCA  FILL2P
3264 2260      ISE  FILL25
3265 1274      TAD  FILL2K
3266 3675      DCA I  FILL2P
3267 2275      ISE  FILL2P
3270 2273      ISE  FILL2C
3271 5245      JMP  ,=4
3272 5460      JMP I  FILL25
3273 0000      FILL2C, 0
3274 2525      FILL2K, 2525
3275 0000      FILL2P, 0

```

```

/SUBROUTINE TO FILL MEMORY WITH 2225,5522,2555
/CALLING SEQUENCE)
/      TAD  (=N          /MINUS (219) NUMBER OF WORDS TO FILL
/      JMS  FILPAT      /CALL SUBROUTINE
/      ADDR          /1ST ADDRESS TO FILL

```

```

3276 0000      FILPAT, 0
3277 3323      DCA  FILLC1
3300 1476      TAD I  FILPAT
3301 3321      DCA  FILLP1
3302 2276      ISE  FILPAT
3303 1325      FILPL1, TAD  FILTP
3304 3322      DCA  FILLP2
3305 1331      TAD  FILTC
3306 3324      DCA  FILLC2
3307 1722      FILPL2, TAD I  FILLP2
3310 3721      DCA I  FILLP1
3311 2321      ISE  FILLP1
3312 2323      ISE  FILLC1
3313 7410      SKP
3314 5676      JMP I  FILPAT
3315 2322      ISE  FILLP2
3316 2324      ISE  FILLC2
3317 5307      JMP  FILPL2
3320 5303      JMP  FILPL1
3321 0000      FILLP1, 0
3322 0000      FILLP2, 0
3323 0000      FILLC1, 0

```

```

3324 0000      FILLC2, 0
3325 3326      FILTP, ,=1
3326 2225      FILTP, 2225
3327 5522      FILTP, 5522
3330 2555      FILTP, 2555
3331 7775      FILTC, FILTP-FILTC+1
3375 4000
3376 4040
3377 4042      PAGE
3400 0000

```

```

/SUBROUTINE TO FILL MEMORY WITH AN INCREMENT PATTERN
/CALLING SEQUENCE)
/      TAD  (=N          /MINUS (219) NUMBER OF WORDS TO FILL
/      JMS  FILINC      /CALL SUBROUTINE
/      ADDR          /1ST ADDRESS TO FILL

```

```

3400 0000      FILINC, 0
3401 3216      DCA  FILICT
3402 1600      TAD I  FILINC
3403 3217      DCA  FILIPT
3404 2200      ISE  FILINC
3405 3220      DCA  FILIDT
3406 1220      TAD  FILIDT
3407 3617      DCA I  FILIPT
3410 2220      ISE  FILIDT
3411 7000      NOP
3412 2217      ISE  FILIPT
3413 2216      ISE  FILICT
3414 5206      JMP  ,=6
3415 5600      JMP I  FILINC
3416 0000      FILICT, 0
3417 0000      FILIPT, 0
3420 0000      FILIDT, 0

```

```

/SUBROUTINE TO FILL MEMORY WITH A DECREMENT PATTERN
/CALLING SEQUENCE)
/      TAD  (=N          /MINUS (219) NUMBER OF WORDS TO FILL
/      JMS  FILDEC      /CALL SUBROUTINE
/      ADDR          /1ST ADDRESS TO FILL

```

```

3421 0000      FILDEC, 0
3422 3240      DCA  FILOCT
3423 1621      TAD I  FILODEC
3424 3241      DCA  FILODT
3425 2221      ISE  FILODEC
3426 3242      DCA  FILODT
3427 1242      TAD  FILODT
3430 3641      DCA I  FILODT
3431 7040      CMA
3432 1242      TAD  FILODT
3433 2241      ISE  FILODT
3434 2240      ISE  FILOCT
3435 5226      JMP  ,=7
3436 7200      CLA

```

3437 3621
3440 0000
3441 0000
3442 0000

JMP I FILDEC
FILDDT, B
FILDDT, B
FILDDT, B

/SUBROUTINE TO FILL MEMORY WITH 6161

/CALLING SEQUENCE1

/ TAD (0N /MINUS (219) NUMBER OF WORDS TO FILL
/ JMS SPEC1 /CALL SUBROUTINE
/ ADDR /1ST ADDRESS TO FILL

3443 0000
3444 3296
3445 1643
3446 3297
3447 2243
3490 1200
3491 3697
3492 2297
3493 2296
3494 5200
3495 5643
3496 0000
3497 0000
3400 6161

SPEC1, B
DCA DCA SPEC1
TAD I TAD I SPEC1
DCA DCA SPEC1
ISE ISE SPEC1
TAD TAD SPEC1D
DCA I DCA I SPEC1
ISE ISE SPEC1
ISE ISE SPEC1
JMP I,=4
JMP I SPEC1
SPEC1, B
SPEC1, B
SPEC1D, 6161

/SUBROUTINE TO FILL MEMORY WITH 3434

/CALLING SEQUENCE1

/ TAD (0N /MINUS (219) NUMBER OF WORDS TO FILL
/ JMS SPEC2 /CALL SUBROUTINE
/ ADDR /1ST ADDRESS TO FILL

3461 0000
3462 3274
3463 1641
3464 3275
3465 2261
3466 1276
3467 3675
3470 2275
3471 2274
3472 5266
3473 5661
3474 0000
3475 0000
3476 3434
3477 0000
3900 4040
3901 1377
3902 4776
3903 2021
3904 7000
3905 1021
3906 4775
3907 1374

SPEC2, B
DCA DCA SPEC2
TAD I TAD I SPEC2
DCA DCA SPEC2
ISE ISE SPEC2
TAD TAD SPEC2D
DCA I DCA I SPEC2
ISE ISE SPEC2
ISE ISE SPEC2
JMP I,=4
JMP I SPEC2
SPEC2, B
SPEC2, B
SPEC2D, 3434
PASCNT, B
JMS CRLF
TAD (PASS
JMS MESSAGE
ISE IN
NOP
TAD IN
JMS DPRINT
TAD (COMP

3910 4776
3911 4040
3912 9677
3913 2001
3914 2323
3915 4000
3916 4003
3917 1715
3920 2014
3921 0324
3922 0300
3974 3316
3975 2316
3976 2244
3977 3513
3600

JMS MESSAGE
JMS CRLF
JMP I PASCNT
PASS, TEXT "PASS"
COMP, TEXT "COMPLETE"
PAGE

/REVERSE SEARCH SUBROUTINE

3600 0000
3601 3270
3602 1034
3603 3095
3604 1377
3605 1776
3606 6774
3607 0776
3610 0375
3611 7640
3612 9563
3613 4774
3614 4774
3615 6771
3616 7410
3617 6777
3620 6771
3621 5220
3622 6776
3623 2373
3624 1372
3625 7490
3626 5240
3627 1371
3630 7640
3631 5215
3632 6776
3633 7006
3634 7032
3635 2095
3636 5206
3637 5261
3640 6776
3641 7006

RSEARCH, B
DCA DCA RSL00K
TAD M10 /SET P A COUNT OF 10 TIMES
DCA BLKTRY /TO SEARCH FOR A BLOCK
TAD (1000
TAD SUNIT
RSRCHB, SDLC
IOT134, SDRC
AND (100
SZA CLA
JMP I (SELERR
JMS RDQUAD
JMS RDQUAD
RSRCH1, SDSS
SKP
IOT135, SDRD
IOT136, SDSS
JMP I,=1
IOT130, SDRC
AND (77
TAD (-26 /BLOCK MARK
SNA
JMP RSRCH2 /YES
TAD (4 /END ZONE
SZA CLA
RSRCH1 /NO, GO READ AGAIN
IOT13A, SDRC /READ THE C.R.
RTL /SET THE DIRECTION BIT IN LINK
CML RTR /INCREMENT IT FOR TURN AROUND
BLKTRY /INCREMENT BLOCK TRY COUNTER
JMP RSRCHB
JMP RSRCHB
RSRCH2, SDRC RSRCH2 /COULDN'T FIND BLOCK AFTER 0 TRIES
RTL

```

3642 6777 10Y137, SDRD /READ THE BLOCK NUMBER
3643 7041 CIA
3644 1270 YAO RLOCK
3645 7450 SNA
3646 5265 JMP RLOCSD
3647 7041 CIA
3648 7420 SNL
3651 1371 YAO (4
3652 7630 SEL CLA
3653 5215 JMP RSRCH1
3654 6776 RETURN, SDRC
3655 7056 RTL
3656 7032 CNL RTR
3657 2055 ISE BLKTRY
3658 5206 JMP RSRCH0
3661 7200 CLA
3662 1270 YAO RLOCK
3663 7402 HLT /ACQTHE BLOCK THAT IT WAS LOOKING FOR
3664 5263 JMP /BUT FAILED TO FIND AFTER 10 TRIES;
3665 7630 RLOCSD, SEL CLA
3666 5215 JMP RSRCH1
3667 5600 JMP I RSRCH
3670 0000 RLOCK, 0
/WRITE REVERSE SUBROUTINE

```

```

3671 0000 WRITER, 0
3672 3770 DCA WCNT
3673 1691 YAO I WRITER
3674 3767 DCA WADDR
3675 2371 ISE WRITER
3676 1691 YAO I WRITER
3677 3766 DCA WOUNT
3678 1271 YAO WRITER
3681 7001 IAO
3682 3769 DCA WRITE
3683 4764 JMS CSUMRY /CALCULATE THE CHECKSUM
3684 0025 ZS
3685 7177 BUFL=1
3686 7000 =200
3687 4763 JMS SBCKOR
3688 4331 JMS WRFLCK /CHECK FOR WRITE LOCK OUT
3689 1770 YAO WCNT
3690 4200 JMS RSRCH
3691 5762 JMP WRITE1
/READ REVERSE SUBROUTINE

```

```

3714 0000 READR, 0
3715 3761 DCA RCNT
3716 1714 YAO I READR
3717 3760 DCA RADDR
3720 2354 ISE READR
3721 1714 YAO I READR
3722 3757 DCA ROUNT
3723 1314 YAO READR
3724 7001 IAO

```

```

3725 3756 DCA READ
3726 1701 YAO RCNT
3727 4200 JMS RSRCH
3730 5755 JMP READ1

3731 0000 WRFLCK, 0 /ROUTINE TO CHECK FOR WRITE LOCKOUT
3732 1776 YAO SUNIT
3733 6774 10Y15A, SDC
3734 6776 10Y15A, SDRC
3735 0304 ANQ (200
3736 7648 SEA CLA
3737 5562 JMP I CHGERR
3740 5731 JMP I WRFLCK

```

```

3754 0200
3755 4612
3756 4000
3757 4660
3760 4657
3761 4656
3762 4512
3763 4714
3764 4303
3765 4672
3766 4545
3767 4544
3770 4470
3771 0004
3772 7752
3773 0077
3774 4707
3775 0100
3776 4471
3777 1000
4000 PAGE

```

/DATA ERROR HANDLER

```

4000 0000 DATERR, 0
4001 7604 LAB
4002 0377 ANQ (400
4003 7648 SEA CLA
4004 5233 JMP DATHLT=3
4005 1240 YAO DATNO
4006 7650 SNA CLA
4007 5220 JMP DATNUM
4008 4200 JMS HEADTP
4009 1240 YAO DATNO
4010 4776 JMS MESSAGE
4011 3240 DCA DATNO
4012 4040 JMS CRLY
4013 1375 YAO (FORMT)
4014 4776 JMS MESSAGE

```

```

4817 4848      JMS      CRLF
4820 1774'    DATNUM, TAD      CPNTR
4821 3241      DCA      DAPPNT
4822 1641      TAD I    DAPPNT
4823 4773'    JMS      OPRINT
4824 1372      TAD      (240
4825 4831      JMS      TYPE
4826 1771'    TAD      TPNTR
4827 3241      DCA      DAPPNT
4828 1641      TAD I    DAPPNT
4831 4773'    JMS      OPRINT
4832 4848      JMS      CRLF
4833 7684      LAS
4834 8378      AND      (200
4835 7658      SZA CLA
4836 7482      DATHLT, HLT
4837 5888      JMP I    DAYERR
4840 8888      DATHD, 0
4841 8888      DATPNT, 0
4842 8481      DATHE, TEXT "DATA ERROR"
4843 2481
4844 4885
4845 2222
4846 1722
4847 8888

```

/SUBROUTINE TO TYPE OUT HEADER FOR DATA TESTS

```

4898 8888      HEADTP, 0
4899 4848      JMS      CRLF
4902 1347      TAD      (UMESS
4903 4776'    JMS      MESSAGE
4904 1372      TAD      (240
4905 4831      JMS      TYPE
4906 6776      IOT139, SRC
4907 7718      SZA CLA
4908 7881      IAC
4909 1346      TAD      (200
4912 4831      JMS      TYPE
4913 4848      JMS      CRLF
4914 1365      TAD      (UMESS
4915 4776'    JMS      MESSAGE
4916 1372      TAD      (240
4917 4831      JMS      TYPE
4918 1827      TAD      BLK
4919 4773'    JMS      OPRINT
4920 4848      JMS      CRLF
4921 1825      TAD      HEAD1
4922 4776'    JMS      MESSAGE
4923 4848      JMS      CRLF
4924 1826      TAD      HEAD2
4925 4776'    JMS      MESSAGE
4926 4848      JMS      CRLF
4927 2916      JMS      CRLF
4928 2916      JMP I    HEADTP
4929 1124      UMESS, TEXT "UNIT"

```

```

4184 8888      BMESS, TEXT "BLOCK"
4185 8214
4186 1783
4187 1388

```

/CHECKSUM ERROR HANDLER

```

4118 8888      CHKERR, 0
4119 3331      DCA      CHKDAT
4122 6776      IOT140, SRC
4123 8364      AND      (4888
4124 6774      IOT141, SOLC
4125 4258      JMS      HEADTP
4126 1343      TAD      (CHKMES
4127 4776'    JMS      MESSAGE
4128 4848      JMS      CRLF
4129 7684      LAS
4130 8378      AND      (200
4131 7648      SZA CLA
4132 9718      JMP I    CHKERR
4133 1331      TAD      CHKDAT
4134 7482      CHKHLT, HLT
4135 7288      CLA
4136 5718      JMP I    CHKERR
4137 8888      CHKDAT, 0
4138 8318      CHKMES, TEXT "CHECKSUM ERROR"
4139 8583
4140 1323
4141 2915
4142 4885
4143 2222
4144 1722
4145 8888

```

PAGE

/WRITE LOCK OUT ERROR

```

4208 4777'    WRORR, JMS      HEADTP
4209 6776      IOT142, SRC

```

/STOP TAPE

```

4292 0376 AND (4888
4293 6774 10T143, SOLC
4294 1375 TAB (WRDMES
4295 4774' JMS MESSAGE
4296 4848 JMS CRLF
4297 7684 LAB
4210 0373 AND (288
4211 7688 SNA CLA
4212 7482 WROHLT, HLT
4213 5772' JMP WREL1+8

4214 2316 WRDMES, TEXT "UNIT WRITE LOCKED"
4215 1124
4216 4827
4217 2211
4220 2483
4221 4814
4222 1783
4223 1385
4224 8488

```

/SELECT ERROR HANDLER

```

4225 4777' SELERR, JMS HEADTP
4226 1371 TAO (SELMES
4227 4774' JMS MESSAGE
4230 4848 JMS CRLF
4231 7684 LAB
4232 0373 AND (288
4233 7688 SNA CLA
4234 7482 SELHLT, HLT
4235 5772' JMP WREL1+8

4236 2389 SELMES, TEXT "SELECT ERROR"
4237 1489
4240 8324
4241 4889
4242 2222
4243 1722
4244 8888

```

/TIMING ERROR HANDLER

```

4245 8888 TYMERR, B
4246 6776 10T144, SORC /STOP TAPE
4247 0376 AND (4888
4250 6774 10T145, SOLC
4251 4777' JMS HEADTP
4252 1378 TAO (TYMMES
4253 4774' JMS MESSAGE
4254 4848 JMS CRLF
4255 7684 LAB
4256 0373 AND (288

```

```

4257 7688 SNA CLA
4260 7482 TYMHLT, HLT
4261 5772' JMP WREAD+8
4262 2411 TYMMES, TEXT "TIMING ERROR"
4263 1311
4264 1687
4265 4889
4266 2222
4267 1722
4270 8888

```

/SUBROUTINE TO CLEAR WRITE AFTER QUAD LINE FLAG

```

4271 8888 CLRNT, B
4272 6773 10T148, SORS /WAIT FOR QUAD LINE FLAG
4273 5272 JMP ,=1
4274 4772 10T154, SOST /TIMING ERROR
4275 7618 SKP CLA /NO
4276 4161 JMS (TYMERR /YES
4277 4776 SORC /READ THE COMMAND REGISTER
4300 8346 AND (7888 /MASK OFF WRITE BIT
4301 6774 10T178, SOLC /LOAD THE COMMAND REGISTER
4302 5671 JMP I CLRNT /EXIT

4303 8888 CSUHRT, B
4304 1783 TAO I CSUHRT
4305 3769' DCA CHKSUM
4306 2383 ISE CSUHRT
4307 1783 TAO I CSUHRT
4310 3817 DCA AUTO
4311 2383 ISE CSUHRT
4312 1783 TAO I CSUHRT
4313 3322 DCA XXX
4314 2383 ISE CSUHRT
4315 1417 TAO I AUTO
4316 4764' JMS SBOXOR
4317 2322 ISE XXX
4320 5315 JMP ,=8
4321 5783 JMP I CSUHRT
4322 8888 XXX, B

4323 8888 CHKCHK, B
4324 4383 JMS CSUHRT
4325 8888 B
4326 7377 BUFF2=1
4327 7575 =283
4330 1769' TAO CHKSUM
4331 7848 CMA
4332 8363 AND (77
4333 7448 SZA
4334 4568 JMS I (CHKERR /CHECK SUM ERROR
4335 5723 JMP I CHKCHK /RETURN

4363 8877
4364 4714

```


4365 4744
4366 7888
4367 3887
4370 4242
4371 4236
4372 3837
4373 8288
4374 2244
4375 4214
4376 4888
4377 4888
4488

PAGE

/T08=EA READ=WRITE=AND=SEARCH SUBROUTINES
/COPYRIGHT 1971, DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS, 01754
/DECTAPE COMMANDS

6771 S0SS=6771 /SKIP ON SINGLE LINE FLAG
6772 SDR0=6772 /SKIP ON TIMING ERROR
6773 S0SQ=6773 /SKIP ON QUADRUPLE LINE FLAG
6774 S0LC=6774 /LOAD COMMAND REGISTER
6775 S0LD=6775 /LOAD DATA REGISTER, CLEAR FLAGS
6776 SDR0=6776 /READ COMMAND REGISTER AND MARK TRACK, CLEAR FLAG
6777 SDRD=6777 /READ DATA REGISTER, CLEAR FLAGS

/SEARCH SUBROUTINE
/SUBROUTINE IS ENTERED WITH THE NUMBER OF THE DESIRED BLOCK IN THE AC
/PROGRAM WILL EXIT WITH TAPE MOVING IN THE FORWARD DIRECTION
/UNIT BIT IS IN SUNIT, BIT 8, BITS 1 TO 11 ARE 8

4488 8888 SEARCH, 8
4481 3278 DCA SLOOK /SAVE BLOCK NUMBER
4482 1894 TAD M18 /SET UP A COUNT OF 18
4483 3895 DCA BLNTRY /TO SEARCH FOR A BLOCK,
4484 1377 TAD (3888 / PUT IN MOTION BACKWARD
4485 1271 TAD SUNIT
4486 6774 SRCH0, S0LC /LOAD CONTROL WITH UNIT, REV, 00, READ
4487 6776 IOT148, SDR0 /READ STATUS
4488 8376 AND (188
4489 7448 SZA CLA /SELECT ERROR?
4490 5963 JMP I CSELERR /YES
4491 4775' JMS R0SUAD /DELAY TO ASSURE
4492 4775' JMS R0SUAD /MARK WINDOW OPEN
4493 6771 SRCH1, S0SS /SINGLE LINE FLAG
4494 7418 SKP /NO
4495 6777 IOT147, SDRD /YES
4496 6771 IOT148, S0SS /SKIP ON SINGLE LINE FLAG
4497 5228 JMP =1
4498 6776 IOT149, SDR0 /READ MARK TRACK AND COMMAND REGISTER
4499 8374 AND (77 /MARK TO MARK TRACK BITS
4500 1373 TAD (=26 /BLOCK MARK ?
4501 7488 SNA
4502 5248 JMP SRCH2 /YES, GO READ THE BLOCK NUMBER
4503 1372 TAD (4 /END ZONE ?

4438 7448 SZA CLA
4439 5215 JMP SRCH1 /NO, GO GET NEXT WORD
4440 6776 IOT14A, SDR0 /READ THE COMMAND REG;
4441 7886 RTL
4442 7832 CHL RTR /TURN THE TAPE AROUND
4443 2895 ISE BLNTRY /8 TRIES ?
4444 5286 JMP SRCH0 /NO, TRY AGAIN
4445 5281 JMP B0DBLK /YES, CAN NOT FIND BLOCK
4446 6776 SRCH2, SDR0 /READ COMMAND REGISTER
4447 7886 RTL /MOVE DIRECTION BIT INTO THE LINK
4448 6777 IOT150, SDRD /GET BLOCK NUMBER FOUND
4449 7841 CIA
4450 1278 TAD SLOOK /COMBINE WITH BLOCK LOOKED FOR
4451 7498 SNA /CURRENT BLOCK?
4452 5263 JMP LOG0ED /YES, CHECK DIRECTION
4453 7841 CIA /NO, TAKE 2'S COMPLEMENT
4454 7428 SNA /LINK IS 1 IF BACKWARD AND NOT AT OR LOWER THAN BLOCK
4455 1371 TAD (2 /ADD TWO TO ENABLE TURN AROUND
4456 7438 SEL CLA /TURN AROUND (3 BEYOND)?
4457 5215 JMP SRCH1 /NO, DON'T TURN AROUND
4458 6776 IOT15B, SDR0 /READ THE COMMAND REGISTER
4459 7886 RTL /MOVE THE DIRECTION BIT INTO LINK
4460 7832 CHL RTR /COMPLEMENT THE DIRECTION BIT
4461 2895 ISE BLNTRY /8 TRIES ?
4462 5286 JMP SRCH0 /NO, GO SEARCH AGAIN
4463 7288 B0DBLK, CLA
4464 1278 TAD SLOOK
4465 7482 HLT /AC=THE BLOCK BEING SEARCHED FOR BUT FAILED
4466 5263 JMP =1 /TO FIND AFTER 8 TRIES
4467 7628 LOC0ED, SNA CLA /FOUND BLOCK FORWARD?
4468 5215 JMP SRCH1 /NO
4469 5688 JMP I SEARCH /YES, EXIT
4470 8888 SLOOK, 8 /BLOCK NUMBER LOOKED FOR
4471 8888 SUNIT, 8 /CURRENT UNIT

/WRITE SUBROUTINE
/CALLING SEQUENCE:
/ TAD (BLKNO /FIRST BLOCK TO BE WRITTEN INTO
/ JMS WRITE /CALL SUBROUTINE
/ ADDRESS /ADDRESS OF FIRST DATA WORD
/ =N /MINUS (2'S) NUMBER OF WORDS TO TRANSFER
/ /RETURN HERE
/128 WORDS PER BLOCK WILL BE WRITTEN FROM MEMORY

4472 8888 WRITE, 8
4473 3278 DCA WCNT /SAVE BLOCK NUMBER
4474 1672 TAD I WRITE
4475 3344 DCA WADDR /SAVE ADDRESS
4476 2272 ISE WRITE
4477 1672 TAD I WRITE
4488 3344 DCA WCOUNT /SAVE WORD COUNT
4489 2272 ISE WRITE
4490 4775' JMS CSUMRT
4491 8825 25

```

4584 7177      BUFF1=1
4585 7888      -288
4586 4767'     JMS      SBCXOR
4587 4766'     JMS      WRTLCK /CHECK FOR WRITE LOCKOUT
4588 1278      TAO      WCNT
4589 4888      JMS      SEARCH /FIND BLOCK
4590 4765'     WRITE1, JMS  REVGRD /WAIT FOR REVERSE GUARD
4591 4775'     JMS      RDQUAD /DELAY TWO-THIRDS THRU LOCK
4592 6776     IOT152, SDRG
4593 1344      TAO      (488
4594 6774     IOT153, SDRG
4595 1343      TAO      (25
4596 4762'     JMS      WRQUAD /WRITE REVERSE CHECKSUM
4597 1744      WRITE2, TAO 1 WADDR /GET THE DATA WORD
4598 2344      JMS      WADDR /INCREMENT ADDRESS
4599 7888      NOP      /SAFETY NOP
4600 4762'     JMS      WRQUAD /WRITE DATA WORD ON TAPE
4601 2345      JMS      WCOUNT /WORD 1287
4602 5381      JMP      WRITE2 /NO
4603 4762'     JMS      WRQUAD /YES WRITE A B (WORD 129)
4604 1761'     TAO      CHKSUM
4605 7848      CMA
4606 8374      AND      (77
4607 7186      RTL      CLL
4608 7886      RTL
4609 7886      RTL
4610 4762'     JMS      WRQUAD /WRITE CHECKSUM
4611 4768'     JMS      CLRNT /WAIT FOR CHECKSUM TO BE WRITTEN,CLEAR "WRITE"
4612 6776     IOT155, SDRG
4613 8387      AND      (4888
4614 6774     IOT156, SDRG
4615 5672      JMP 1     /STOP TAPE
4616 4478      WCNT=BLOCK /BLOCK NUMBER, ALSO BLOCK DATA COUNTER
4617 8888      WADDR, 8 /WORD ADDRESS
4618 8888      WCOUNT, 8 /WORD COUNT

4597 4888
4598 4271
4599 4744
4600 4781
4601 8825
4602 8488
4603 4661
4604 3731
4605 4714
4606 4383
4607 8882
4608 8884
4609 7792
4610 8877
4611 4787
4612 8188
4613 3888
4614 4688

```

PAGE

```

/READ SUBROUTINE
/CALLING SEQUENCE:
/ TAO 18LKNO /FIRST BLOCK TO BE READ FROM
/ JMS READ /CALL SUBROUTINE
/ ADDRESS /ADDRESS FOR FIRST DATA WORD
/ -N /MINUS (219) NUMBER OF WORDS TO TRANSFER
/ /RETURN HERE
/128 WORDS PER BLOCK WILL BE READ INTO MEMORY

4688 8888 READ, 8
4689 3236 DCA RCNT /SAVE BLOCK NUMBER
4690 1688 TAO 1 READ
4691 3237 DCA RADDR /SAVE ADDRESS
4692 2288 JMS READ
4693 1688 TAO 1 READ
4694 3248 DCA RCOUNT /SAVE WORD COUNT
4695 2288 JMS READ
4696 1856 TAO RCNT
4697 4777' JMS SEARCH /FIND BLOCK
4698 4771' READ1, SDRS /WAIT FOR REVERSE GUARD
4699 5212 JMP 1=1
4700 6776 IOT15A, SDRG
4701 8376 AND (77 /READ THE MARK TRACK
4702 1375 TAO (32
4703 7488 SNA /REVERSE GUARD
4704 9225 JMP 1=5 /YES, EXIT
4705 1374 TAO (18 /NO
4706 7648 SRA CLA /END ZONE ?
4707 5212 JMP READ1 /NO
4708 5274 JMP IOT162 /YES STOP TAPE
4709 4387 JMS RDQUAD
4710 4387 JMS RDQUAD /WAIT FOR
4711 8376 JMS RDQUAD /REVERSE CHECKSUM
4712 8376 AND (77 /MASK
4713 7418 SKP /STORE THE WORD
4714 4387 READ2, JMS RDQUAD /GET DATA WORD
4715 3687 DCA 1 RADDR
4716 2287 JMS RADDR
4717 7888 NOP /SAFETY NOP
4718 2288 JMS RCOUNT /128 DATA WORDS?
4719 5292 JMP READ2 /NO
4720 4387 JMS RDQUAD /YES, GET WORD 129
4721 3687 DCA 1 RADDR /STORE IT
4722 2287 JMS RADDR
4723 4387 JMS RDQUAD /GET FORWARD CHECKSUM

4644 8373 AND (7788
4645 3687 DCA 1 RADDR
4646 6772 IOT157, SDRS
4647 7418 SKP
4648 4961 JMS 1 CTHERR /TIMING ERROR
4649 6776 IOT158, SDRG
4650 8372 AND (4888

```

```

4653 6774 10T159, SOLC /STOP TAPE
4654 4771 JMS CHKCHK /CALCULATE AND CHECK CHECK SUM
4655 5600 JMP I READ
4656 0000 RCNT, 0 /BLOCK NUMBER, ALSO BLOCK DATA COUNTER
4657 0000 RADDR, 0 /WORD ADDRESS
4658 0000 RCOUNT, 0 /WORD COUNT

/WAIT FOR REVERSE GUARD SUBROUTINE
4661 0000 REVGRD, 0
4662 6771 10T160, SOSS /WAIT FOR MARK TRACK CHANGE
4663 5242 JMP I=I
4664 6776 10T161, SDRC /READ MARK TRACK
4665 0376 AND (77
4666 1375 TAD (=32
4667 7499 SNA /REVERSE GUARD?
4668 5661 JMP I REVGRD /YES, EXIT?
4671 1374 TAD (10 /NO
4672 7648 SZA CLA /END EDNE?
4673 5242 JMP REVGRD+1 /NO
4674 6776 10T162, SDRC /YES, STOP TAPE
4675 0372 AND (4000
4676 6774 10T163, SOLC
4677 7402 WLI
4678 5277 JMP I=I /NON-RECOVERABLE ERROR, PROGRAM
/FOUND ENDZONE WHILE LOOKING FOR REV GRD
/BLOCK PROBABLY ABOVE 2771

/WRITE A "QUAD WORD" (12 BIT WORD) SUBROUTINE
4701 0000 WRQUAD, 0
4702 6773 10T164, SDSQ /WAIT FOR NEXT QUAD FLAG
4703 5302 JMP I=I
4704 6775 10T165, SOLD /LOAD DATA BUFFER TO WRITE ON TAPE
4705 7600 M02B0A, CLA+400 /CLEAR AC
4706 5701 JMP I WRQUAD /EXIT

/READ A "QUAD WORD" (12 BIT WORD) SUBROUTINE
4707 0000 RDQUAD, 0
4708 6773 10T166, SDSQ /WAIT FOR QUAD FLAG
4711 5310 JMP I=I
4712 6777 10T167, SDRD /READ DATA BUFFER, CLEAR FLAG
4713 5707 JMP I RDQUAD

/SIXBIT COMPLEMENT XOR SUBROUTINE
/SUBROUTINE IS ENTERED WITH DATA WORD TO BE XORED IN AC
/TWO 6-BIT COMPLEMENT XORS WILL TAKE PLACE TO LOCATION CHKSUM
/WITH THE RESULT IN CHKSUM

4714 0000 SBCKXOR, 0
4715 7040 DCA /COMPLEMENT WORD
4716 3349 DCA SBWORD /AND SAVE
4717 1345 TAD SBWORD
4720 0344 AND CHKSUM
4721 7041 CIA
4722 7104 CLL RAL
4723 1345 TAD SBWORD
4724 1344 TAD CHKSUM
    
```

```

4725 3344 DCA CHKSUM
4726 1345 TAD SBWORD
4727 7112 RTR CLL; RTR; RTR

4730 7012
4731 7012
4732 3349 DCA SBWORD
4733 1345 TAD SBWORD
4734 0344 AND CHKSUM
4735 7041 CIA
4736 7104 CLL RAL
4737 1345 TAD SBWORD
4740 1344 TAD CHKSUM
4741 0376 AND (77
4742 3344 DCA CHKSUM
4743 5714 JMP I SBCKXOR
4744 0000 CHKSUM, 0
4745 0000 SBWORD,

4771 4323
4772 4000
4773 7700
4774 0010
4775 7746
4776 0077
4777 4400
5000 PAGE

/MESSAGES
5000 1417 MESS1, TEXT "LOAD AND READ DATA REGISTER ERROR"
5001 0104
5002 4001
5003 1604
5004 4022
5005 0501
5006 0440
5007 0401
5010 2401
5011 4022
5012 0507
5013 1123
5014 2405
5015 2240
5016 0522
5017 2217
5020 2200
5021 1417 MESS2, TEXT "LOAD AND READ COMMAND REGISTER ERROR"
5022 0104
5023 4001
5024 1604
5025 4022
5026 0501
5027 0440
    
```

9038 0317
 9031 1919
 9032 0116
 9033 0448
 9034 2209
 9035 0711
 9036 2324
 9037 0922
 9040 4009
 9041 2222
 9042 1722
 9043 0000
 9044 1116
 9045 1124
 9046 1101
 9047 1411
 9050 3209
 9051 4024
 9052 0923
 9053 2400
 9054 0301
 9055 0640
 9056 0411
 9057 0440
 9060 1017
 9061 2440
 9062 0314
 9063 0901
 9064 2240
 9065 0317
 9066 1919
 9067 0116
 9070 0440
 9071 2209
 9072 0711
 9073 2324
 9074 0922
 9075 0000
 9076 0310
 9077 0903
 9100 1340
 9101 2304
 9102 1403
 9103 3440
 9104 2304
 9105 1404
 9106 3440
 9107 2304
 9110 2203
 9111 3440
 9112 2304
 9113 2204
 9114 4001
 9115 1004
 9116 4001

MESS3, TEXT "INITIALIZE TEST"

MESS4, TEXT "CAF DID NOT CLEAR COMMAND REGISTER"

MESS5, TEXT "CHECK SOLC, SLD, SRC, SORD AND AC CLEAR"

9117 0340
 9120 0314
 9121 0501
 9122 2200
 9123 2304
 9124 1403
 9125 4004
 9126 1104
 9127 4016
 9130 1724
 9131 4003
 9132 1409
 9133 0122
 9134 4001
 9135 0300
 9136 2304
 9137 2203
 9140 4004
 9141 1104
 9142 4016
 9143 1724
 9144 4003
 9149 1409
 9146 0122
 9147 4001
 9150 0300
 9151 2304
 9152 1404
 9153 4003
 9154 1409
 9155 0122
 9156 0504
 9157 4001
 9160 0300
 9161 2304
 9162 2204
 9163 4004
 9164 1104
 9165 4016
 9166 1724
 9167 4003
 9170 1409
 9171 0122
 9172 4001
 9173 0300
 9174 2311
 9175 1007
 9176 1409
 9177 4014
 9200 1116
 9201 0740
 9202 0614
 9203 0107
 9204 4023
 9205 1311

MESS6, TEXT "SOLC DID NOT CLEAR AC"

MESS7, TEXT "SRC DID NOT CLEAR AC"

MESS8, TEXT "SOLD CLEARED AC"

MESS9, TEXT "SORD DID NOT CLEAR AC"

MESS10, TEXT "SINGLE LINE FLAG SKIP INSTRUCTION AND LOGIC"

9206 2040
 9207 1116
 9210 2324
 9211 2225
 9212 0324
 9213 1117
 9214 1040
 9215 0116
 9216 0440
 9217 1417
 9220 0711
 9221 0300
 9222 2311
 9223 1007
 9224 1405
 9225 4014
 9226 1116
 9227 0540
 9230 0014
 9231 0107
 9232 4001
 9233 1427
 9234 0131
 9235 2340
 9236 2305
 9237 2440
 9240 1722
 9241 4023
 9242 0423
 9243 2340
 9244 0114
 9245 2701
 9246 3123
 9247 4023
 9250 1311
 9251 2023
 9252 0000
 9253 2311
 9254 1007
 9255 1405
 9256 4014
 9257 1116
 9260 0540
 9261 0614
 9262 0107
 9263 4004
 9264 1705
 9265 2340
 9266 1017
 9267 2440
 9270 2305
 9271 2440
 9272 1722
 9273 4023
 9274 0423

MESS11, TEXT "SINGLE LINE FLAG ALWAYS SET OR SDS5 ALWAYS SKIPS"

MESS12, TEXT "SINGLE LINE FLAG DOES NOT SET OR SDS5 DOES NOT SKIP"

9275 2340
 9276 0417
 9277 0923
 9300 4016
 9301 1724
 9302 4023
 9303 1311
 9304 2000
 9305 2311
 9306 1007
 9307 1405
 9310 4014
 9311 1116
 9312 0540
 9313 0014
 9314 0107
 9315 4003
 9316 1405
 9317 0122
 9320 0504
 9321 4002
 9322 3140
 9323 2304
 9324 2323
 9325 0000
 9326 2311
 9327 1007
 9330 1405
 9331 4014
 9332 1116
 9333 0540
 9334 0014
 9335 0107
 9336 4016
 9337 1724
 9340 4003
 9341 1405
 9342 0122
 9343 0504
 9344 4002
 9345 3140
 9346 0301
 9347 0600
 9350 2311
 9351 1007
 9352 1405
 9353 4014
 9354 1116
 9355 0540
 9356 0014
 9357 0107
 9360 4016
 9361 1724
 9362 4003
 9363 1405

MESS13, TEXT "SINGLE LINE FLAG CLEARED BY SDS9"

MESS14, TEXT "SINGLE LINE FLAG NOT CLEARED BY CAP"

MESS15, TEXT "SINGLE LINE FLAG NOT CLEARED BY \$DL0"

5364	0122		
5365	0504		
5366	4002		
5367	3140		
5370	2304		
5371	1404		
5372	0000		
5373	2311	MESS16, TEXT	"SINGLE LINE FLAG NOT CLEARED BY SDRD"
5374	1607		
5375	1405		
5376	4014		
5377	1110		
5400	0940		
5401	0014		
5402	0107		
5403	4016		
5404	1724		
5405	4003		
5406	1405		
5407	0122		
5410	0504		
5411	4002		
5412	3140		
5413	2304		
5414	2203		
5415	0000		
5416	2311	MESS17, TEXT	"SINGLE LINE FLAG NOT CLEARED BY SDRD"
5417	1607		
5420	1405		
5421	4014		
5422	1110		
5423	0940		
5424	0014		
5425	0107		
5426	4016		
5427	1724		
5430	4003		
5431	1405		
5432	0122		
5433	0504		
5434	4002		
5435	3140		
5436	2304		
5437	2204		
5440	0000		
5441	2311	MESS18, TEXT	"SINGLE LINE FLAG CLEARED BY SOST, S0S0, OR S0LC"
5442	1607		
5443	1405		
5444	4014		
5445	1110		
5446	0940		
5447	0014		
5450	0107		
5451	4003		
5452	1405		

5453	0122		
5454	0504		
5455	4002		
5456	3140		
5457	2304		
5460	2324		
5461	5440		
5462	2304		
5463	2301		
5464	5440		
5465	1722		
5466	4003		
5467	0014		
5470	0300		
5471	2105	MESS19, TEXT	"QUAD LINE FLAG SKIP INSTRUCTION AND LOGIC"
5472	0104		
5473	4014		
5474	1110		
5475	0940		
5476	0014		
5477	0107		
5500	4003		
5501	1311		
5502	2040		
5503	1110		
5504	2304		
5505	2225		
5506	0304		
5507	1117		
5510	1040		
5511	0110		
5512	0440		
5513	1417		
5514	0711		
5515	0300		
5516	2105	MESS20, TEXT	"QUAD LINE FLAG ALWAYS SET OR S0S0 ALWAYS SKIPS"
5517	0104		
5520	4014		
5521	1110		
5522	0940		
5523	0014		
5524	0107		
5525	4001		
5526	1407		
5527	0131		
5530	2340		
5531	2305		
5532	2440		
5533	1722		
5534	4003		
5535	4003		
5536	0140		
5537	0114		
5540	2701		
5541	3103		

5542	4023		
5543	1311		
5544	2023		
5545	0000		
5546	2125	MESS21, TEXT	"QUAD LINE FLAG SET TOO SOON"
5547	0104		
5550	4014		
5551	1116		
5552	0940		
5553	0014		
5554	0107		
5555	4023		
5556	0524		
5557	4024		
5560	1717		
5561	4023		
5562	1717		
5563	1400		
5564	2125	MESS22, TEXT	"QUAD LINE FLAG DOES NOT SET OR S030 DOES NOT SKIP"
5565	0104		
5566	4014		
5567	1116		
5570	0940		
5571	0014		
5572	0107		
5573	4004		
5574	1705		
5575	2340		
5576	1617		
5577	2440		
5600	2305		
5601	2440		
5602	1722		
5603	4023		
5604	0423		
5605	2140		
5606	0417		
5607	0523		
5610	4016		
5611	1724		
5612	4023		
5613	1311		
5614	2000		
5615	2125	MESS23, TEXT	"QUAD LINE FLAG CLEARED BY S050"
5616	0104		
5617	4014		
5620	1116		
5621	0940		
5622	0614		
5623	0107		
5624	4003		
5625	1405		
5626	0122		
5627	0504		
5630	4002		

5631	3140		
5632	2304		
5633	2321		
5634	0000		
5635	2125	MESS24, TEXT	"QUAD LINE FLAG NOT CLEARED BY CAP"
5636	0104		
5637	4014		
5640	1116		
5641	0940		
5642	0614		
5643	0107		
5644	4016		
5645	1724		
5646	4003		
5647	1405		
5650	0122		
5651	0504		
5652	4002		
5653	3140		
5654	0301		
5655	0400		
5656	2125	MESS25, TEXT	"QUAD LINE FLAG NOT CLEARED BY S0LD"
5657	0104		
5660	4014		
5661	1116		
5662	0940		
5663	0014		
5664	0107		
5665	4016		
5666	1724		
5667	4003		
5670	1405		
5671	0122		
5672	0504		
5673	4002		
5674	3140		
5675	2304		
5676	1404		
5677	0000		
5700	2125	MESS26, TEXT	"QUAD LINE FLAG NOT CLEARED BY SDRM"
5701	0104		
5702	4014		
5703	1116		
5704	0940		
5705	0614		
5706	0107		
5707	4016		
5710	1724		
5711	4003		
5712	1405		
5713	0122		
5714	0504		
5715	4002		
5716	3140		
5717	2304		

5720 2203
 5721 0800
 5722 2125
 5723 0104
 5724 4014
 5725 1116
 5726 0940
 5727 0014
 5730 0107
 5731 4016
 5732 1724
 5733 4003
 5734 1405
 5735 0122
 5736 0904
 5737 4002
 5740 3140
 5741 2304
 5742 2204
 5743 0800
 5744 2125
 5745 0104
 5746 4014
 5747 1116
 5750 0940
 5751 0014
 5752 0107
 5753 4003
 5754 1405
 5755 0122
 5756 0904
 5757 4002
 5760 3140
 5761 2304
 5762 2304
 5763 5440
 5764 2304
 5765 2323
 5766 5440
 5767 1722
 5770 4023
 5771 0414
 5772 0300
 5773 2125
 5774 0104
 5775 4014
 5776 1116
 5777 0940
 0800 0014
 0801 0107
 0802 4003
 0803 1725
 0804 1024
 0805 0922
 0806 4006

MESS27, TEXT "QUAD LINE FLAG NOT CLEARED BY SORD"

MESS28, TEXT "QUAD LINE FLAG CLEARED BY SOST, SOSS, OR WOLC"

MESS29, TEXT "QUAD LINE FLAG COUNTER FLIP/FLOP NOT PROPERLY CLEARED"

0807 1411
 0810 2057
 0811 0014
 0812 1720
 0813 4016
 0814 1724
 0815 4020
 0816 2217
 0817 2005
 0820 2214
 0821 3140
 0822 0314
 0823 0901
 0824 2205
 0825 0400

MESS30, TEXT "TIMING ERROR SKIP INSTRUCTION AND LOGIC"

0826 2411
 0827 1511
 0830 1407
 0831 4005
 0832 2222
 0833 1722
 0834 4023
 0835 1311
 0836 2040
 0837 1116
 0840 2324
 0841 2225
 0842 0324
 0843 1117
 0844 1040
 0845 0116
 0846 0440
 0847 1417
 0850 0711
 0851 0300
 0852 2411
 0853 1511
 0854 1407
 0855 4005
 0856 2222
 0857 1722
 0860 4001
 0861 1427
 0862 0131
 0863 2340
 0864 2305
 0865 2440
 0866 1722
 0867 4023
 0870 0423
 0871 2440
 0872 0114

MESS31, TEXT "TIMING ERROR ALWAYS SET OR SOST ALWAYS SKIP"

6073	2781		
6074	3123		
6075	4083		
6076	1381		
6077	2023		
6100	0000		
6101	2411	MESS32, TEXT	"TIMING ERROR DOES NOT SET IN READ MODE OR SDS? DOES NOT SKIP"
6102	1911		
6103	1687		
6104	4089		
6105	2222		
6106	1722		
6107	4084		
6110	1709		
6111	2340		
6112	1617		
6113	2440		
6114	2305		
6115	2440		
6116	1116		
6117	4022		
6120	0901		
6121	0440		
6122	1917		
6123	0409		
6124	4017		
6125	2840		
6126	2304		
6127	2304		
6130	4004		
6131	1709		
6132	2340		
6133	1617		
6134	2440		
6139	2313		
6136	1120		
6137	0000		
6140	2411	MESS33, TEXT	"TIMING ERROR CLEARED BY 9DSY"
6141	1911		
6142	1687		
6143	4089		
6144	2222		
6145	1722		
6146	4003		
6147	1409		
6150	0122		
6151	0904		
6152	4002		
6153	3140		
6154	2304		
6155	2304		
6156	0000		
6157	2411	MESS34, TEXT	"TIMING ERROR NOT CLEARED BY CAF"
6160	1911		
6161	1687		

6162	4009		
6163	2222		
6164	1722		
6165	4016		
6166	1724		
6167	4003		
6170	1409		
6171	0122		
6172	0904		
6173	4002		
6174	3140		
6175	0301		
6176	0600		
6177	2411	MESS35, TEXT	"TIMING ERROR STATUS BIT NOT SET IN COMMAND REGISTER"
6200	1911		
6201	1687		
6202	4009		
6203	2222		
6204	1722		
6205	4023		
6206	2401		
6207	2405		
6210	2340		
6211	0211		
6212	2440		
6213	1617		
6214	2440		
6215	2305		
6216	2440		
6217	1116		
6220	4003		
6221	1715		
6222	1901		
6223	1684		
6224	4022		
6225	0907		
6226	1123		
6227	2405		
6230	2200		
6231	2411	MESS36, TEXT	"TIMING ERROR NOT CLEARED BY SDC"
6232	1911		
6233	1687		
6234	4009		
6235	2222		
6236	1722		
6237	4016		
6240	1724		
6241	4003		
6242	1409		
6243	0122		
6244	0904		
6245	4002		
6246	3140		
6247	2304		
6250	1403		

6251 0000
 6252 2411
 6253 1511
 6254 1607
 6255 4000
 6256 2222
 6257 1722
 6200 4004
 6201 1700
 6202 2340
 6203 1617
 6204 2440
 6205 2300
 6206 2440
 6207 1110
 6270 4027
 6271 2211
 6272 2400
 6273 4010
 6274 1704
 6275 0000
 6276 2411
 6277 1911
 6300 1607
 6301 4000
 6302 2222
 6303 1722
 6304 4004
 6305 1700
 6306 2340
 6307 1617
 6308 2440
 6311 0314
 6312 0001
 6313 2240
 6314 2722
 6315 1124
 6316 0040
 6317 0614
 6320 1120
 6321 0706
 6322 1417
 6323 2000
 6324 2411
 6325 1911
 6326 1607
 6327 4000
 6330 2202
 6331 1722
 6332 4016
 6333 1724
 6334 4000
 6335 0024
 6336 4002
 6337 3140

MESS37, TEXT "TIMING ERROR DOES NOT SET IN WRITE MODE"

MESS38, TEXT "TIMING ERROR DOES NOT CLEAR WRITE FLIP/FLOP"

MESS39, TEXT "TIMING ERROR NOT SET BY \$DR0 \$DRD, OR \$DLC"

6340 2304
 6341 2200
 6342 4000
 6343 0422
 6344 0404
 6345 4017
 6346 2240
 6347 2304
 6350 1400
 6351 0000
 6352 2000
 6353 4024
 6354 1740
 6355 2000
 6356 0000
 6357 0440
 6360 0011
 6361 2200
 6362 2011
 6363 2422
 6364 3140
 6365 0310
 6366 0000
 6367 1340
 6370 2000
 6371 1116
 6372 0740
 6373 4700
 6374 1400
 6375 0122
 6376 4010
 6377 0122
 6400 1340
 6401 2422
 6402 0100
 6403 1340
 6404 2000
 6405 0711
 6406 2324
 6407 0022
 6410 4740
 6411 0400
 6412 0124
 6413 2022
 6414 0000
 6415 1901
 6416 2210
 6417 4024
 6420 2201
 6421 0310
 6422 4002
 6423 0007
 6424 1100
 6425 2400
 6426 2240

MESS43, TEXT "UP TO SPEED CIRCUITRY CHECK USING 'CLEAR MARK TRACK REGISTER' FEATURE"

MESS44, TEXT "MARK TRACK REGISTER NOT CLEARED BY 'GO!'"

6427 1617
 6430 2440
 6431 0314
 6432 0501
 6433 2205
 6434 0440
 6435 0231
 6436 4047
 6437 0717
 6440 4700
 6441 1501
 6442 2213
 6443 4024
 6444 2201
 6445 0313
 6446 4022
 6447 0507
 6450 1123
 6451 2405
 6452 2240
 6453 1617
 6454 2440
 6455 0314
 6456 0501
 6457 2205
 6460 0440
 6461 0231
 6462 4047
 6463 2324
 6464 1700
 6465 4700
 6466 1501
 6467 2213
 6470 4024
 6471 2201
 6472 0313
 6473 4022
 6474 0507
 6475 1123
 6476 2405
 6477 2240
 6500 1617
 6501 2440
 6502 0314
 6503 0501
 6504 2205
 6505 0440
 6506 0231
 6507 4047
 6510 2205
 6511 2647
 6512 4024
 6513 1740
 6514 4700
 6515 2704

MESS45, TEXT "MARK TRACK REGISTER NOT CLEARED BY /STOP/"

MESS46, TEXT "MARK TRACK REGISTER NOT CLEARED BY /REV/ TO /FWD/"

6516 4700
 6517 1501
 6520 2213
 6521 4024
 6522 2201
 6523 0313
 6524 4022
 6525 0507
 6526 1123
 6527 2405
 6530 2240
 6531 1617
 6532 2440
 6533 0314
 6534 0501
 6535 2205
 6536 0440
 6537 0231
 6540 4047
 6541 0627
 6542 0447
 6543 4024
 6544 1740
 6545 4722
 6546 0526
 6547 4700
 6550 1501
 6551 2213
 6552 4024
 6553 2201
 6554 0313
 6555 4022
 6556 0507
 6557 1123
 6560 2405
 6561 2240
 6562 1617
 6563 2440
 6564 0314
 6565 0501
 6566 2205
 6567 0440
 6570 0231
 6571 4047
 6572 2516
 6573 1124
 6574 4060
 6575 4740
 6576 2417
 6577 4047
 6600 2916
 6601 1124
 6602 4061
 6603 4700
 6604 1501

MESS47, TEXT "MARK TRACK REGISTER NOT CLEARED BY /FWD/ TO /REV/"

MESS48, TEXT "MARK TRACK REGISTER NOT CLEARED BY /UNIT 0/ TO /UNIT 1/"

MESS49, TEXT "MARK TRACK REGISTER NOT CLEARED BY /UNIT 1/ TO /UNIT 0/"

6605 2213
 6606 4824
 6607 2201
 6610 0313
 6611 4822
 6612 0507
 6613 1123
 6614 2405
 6615 2248
 6616 1617
 6617 2448
 6620 0314
 6621 0501
 6622 2205
 6623 0448
 6624 0231
 6625 4847
 6626 2514
 6627 1124
 6630 4801
 6631 4748
 6632 2417
 6633 4847
 6634 2516
 6635 1124
 6636 4848
 6637 4708
 6648 4723
 6641 0514
 6642 0503
 6643 2448
 6644 0522
 6645 2217
 6646 2247
 6647 4824
 6650 0523
 6651 2423
 6652 0808
 6653 2411
 6654 1511
 6655 1607
 6656 4805
 6657 2222
 6660 1722
 6661 4823
 6662 0524
 6663 0808
 6664 1617
 6665 4823
 6666 0514
 6667 0503
 6670 2448
 6671 0522
 6672 2217
 6673 2248

MESS00, TEXT "/SELECT ERROR' TESTS"

MESS01, TEXT "TIMING ERROR SET"

MESS02, TEXT "NO SELECT ERROR STATUS FROM UNIT I"

6674 2324
 6675 0124
 6676 2523
 6677 4806
 6700 2217
 6701 1548
 6702 2516
 6703 1124
 6704 4861
 6705 0808
 6706 4727
 6707 2211
 6710 2405
 6711 4748
 6712 1617
 6713 2448
 6714 0314
 6715 0501
 6716 2205
 6717 0448
 6720 0231
 6721 4823
 6722 0514
 6723 0503
 6724 2448
 6725 0522
 6726 2217
 6727 2208
 6730 4727
 6731 2211
 6732 2405
 6733 4814
 6734 1703
 6735 1348
 6736 1725
 6737 2447
 6740 4824
 6741 0523
 6742 2423
 6743 0808
 6744 1617
 6745 4827
 6746 2211
 6747 2405
 6750 4814
 6751 1703
 6752 1348
 6753 1725
 6754 2448
 6755 2324
 6756 0124
 6757 2523
 6760 4806
 6761 2217
 6762 1548

MESS03, TEXT "WRITE' NOT CLEARED BY SELECT ERROR"

MESS04, TEXT "WRITE LOCK OUT' TESTS"

MESS05, TEXT "NO WRITE LOCK OUT STATUS FROM UNIT B"

6763	2916		
6764	1124		
6765	4060		
6766	0000		
6767	4727	MESS56, TEXT	"WRITE' NOT CLEARED BY WRITE LOCK OUT"
6770	2211		
6771	2405		
6772	4740		
6773	1617		
6774	2440		
6775	0314		
6776	0501		
6777	2205		
7000	0440		
7001	0231		
7002	4027		
7003	2211		
7004	2405		
7005	4014		
7006	1703		
7007	1340		
7010	1723		
7011	2400		
7012	0401	MESS57, TEXT	"DATA WRITTEN FORWARD"
7013	2401		
7014	4027		
7015	2211		
7016	2424		
7017	0516		
7020	4006		
7021	1722		
7022	2701		
7023	2204		
7024	0000		
7025	2722	MESS58, TEXT	"WRITE DATA FORWARD"
7026	1124		
7027	0540		
7030	0401		
7031	2401		
7032	4006		
7033	1722		
7034	2701		
7035	2204		
7036	0000		
7037	2205	MESS59, TEXT	"READ DATA FORWARD"
7040	0104		
7041	4004		
7042	0124		
7043	0140		
7044	0617		
7045	2227		
7046	0122		
7047	0400		
7050	2205	MESS60, TEXT	"READ DATA BACKWARD"
7051	0104		

7052	4004		
7053	0124		
7054	0140		
7055	0201		
7056	0313		
7057	2701		
7060	2204		
7061	0000		
7062	0401	MESS61, TEXT	"DATA WRITTEN BACKWARD"
7063	2401		
7064	4027		
7065	2211		
7066	2424		
7067	0516		
7070	4002		
7071	0103		
7072	1327		
7073	0122		
7074	0400		
7075	2722	MESS62, TEXT	"WRITE DATA BACKWARD"
7076	1124		
7077	0540		
7100	0401		
7101	2401		
7102	4002		
7103	0103		
7104	1327		
7105	0122		
7106	0400		
7107	1617	MESS63, TEXT	"NO UNIT 0 SELECTED"
7110	4023		
7111	1611		
7112	2440		
7113	0040		
7114	2305		
7115	1405		
7116	0324		
7117	0504		
7120	0000		

7200

PAGE
 /ROUTINE TO CHANGE ALL TDBE IOYS IN PROGRAM FOR MULTIPLE UNIT
 /ROUTINE IS STARTED AT LOCATION "MODIFY" WITH AC6,7 AND 8 INDICATING
 /DEVICE SELECTOR BITS 6, 7, AND 8 OF THE CONTROL TO BE TESTED (4,5,6, OR 7)

7200	7604	MODIFY, LAS	
7201	0221	AND	MODMS1
7202	3223	DCA	MODCON
7203	1230	TAD	MODTAB
7204	3224	DCA	MODPT1
7205	1227	TAD	MODSIZ
7206	3226	DCA	MODCNT
7207	1024	MODLUP, TAD I	MODPT1

7210	3225	DCA	MODPT2
7211	1625	TAD I	MODPT2
7212	8222	AND	MODMS2
7213	1223	TAD	MODCON
7214	3625	OCA I	MODPT2
7215	2224	ISE	MODPT1
7216	2226	ISE	MODCNT
7217	5287	JMP	MODLUP
7220	7482	HLT	
7221	8838	MODMS1,	38
7222	7747	MODMS2,	7747
7223	8888	MODCON,	8
7224	8888	MODPT1,	8
7225	8888	MODPT2,	8
7226	8888	MODCNT,	8
7227	7461	MODSIE,	=MODEND+MODTAB
7230	7231	MODTAB,	+1
7231	8287		10T1
7232	8212		10T2
7233	8214		10T3
7234	8244		10T4
7235	8246		10T5
7236	8313		10T6
7237	8328		10T7
7240	8486		10T8
7241	8423		10T9
7242	8425		10T10
7243	8442		10T11
7244	8437		10T12
7245	8461		10T13
7246	8686		10T14
7247	8612		10T15
7250	8621		10T16
7251	8636		SING1
7252	8645		SING2
7253	8693		10T17
7254	8662		10T18
7255	8665		SING3
7256	8678		10T19
7257	8674		10T20
7260	8784		SING4
7261	8787		10T21
7262	8713		10T22
7263	8723		SING5
7264	8726		10T23
7265	8732		10T24
7266	1882		SING6
7267	1884		10T25
7270	1886		10T26
7271	1811		10T27
7272	1812		10T28
7273	1832		10T29
7274	1836		10T30

7275	1841		QUAD8
7276	1842		10T31
7277	1844		10T32
7300	1898		10T33
7301	1853		10T34
7302	1897		10T35
7303	1861		10T36
7304	1867		10T37
7305	1872		10T38
7306	1101		QUAD1
7307	1118		QUAD2
7310	1116		10T39
7311	1125		10T40
7312	1138		QUAD3
7313	1133		10T41
7314	1137		10T42
7315	1202		QUAD4
7316	1285		10T43
7317	1211		10T44
7320	1221		QUAD5
7321	1224		10T45
7322	1238		10T46
7323	1248		QUAD6
7324	1242		10T47
7325	1244		10T48
7326	1258		10T49
7327	1254		10T50
7330	1270		10T51
7331	1271		10T52
7332	1273		10T53
7333	1276		10T54
7334	1385		10T55
7335	1324		10T56
7336	1325		10T57
7337	1327		10T58
7340	1334		TIME8
7341	1342		10T59
7342	1393		TIME1
7343	1482		TIME2
7344	1418		10T60
7345	1417		10T61
7346	1422		TIME3
7347	1424		10T62
7350	1442		10T63
7351	1445		TIME4
7352	1447		10T64
7353	1493		10T65
7354	1468		10T66
7355	1466		10T67
7356	1478		10T68
7357	1475		10T69
7360	1508		10T70
7361	1564		10T71

7362	1918	10T72
7363	1923	10T73
7364	1924	10T74
7365	1931	10T75
7366	1932	10T76
7367	1933	10T77
7378	1943	10T78
7371	1685	10T82
7372	1687	10T83
7373	1613	10T84
7374	1626	10T89
7375	1627	10T86
7376	1631	10T87
7377	1635	10T88
7488	1641	10T89
7481	1654	10T98
7482	1655	10T91
7483	1657	10T92
7484	1664	10T93
7485	1678	10T94
7486	1783	10T95
7487	1784	10T96
7418	1786	10T97
7411	1713	10T98
7412	1717	10T99
7413	2884	10T108
7414	2885	10T101

7415	2887	10T102
7416	2814	10T103
7417	2828	10T104
7428	2837	10T105
7421	2848	10T106
7422	2842	10T107
7423	2847	10T108
7424	2853	10T109
7425	2865	10T118
7426	2284	10T211
7427	2286	DISLUP
7438	2211	10T112
7431	2213	10T113
7432	2227	10T114
7433	2241	10T115
7434	2253	10T116
7435	2482	10T117
7436	2418	10T118
7437	2413	10T119
7448	2518	10T128
7441	2512	10T121
7442	2528	10T122
7443	2522	10T123
7444	2685	10T124
7445	2686	10T125
7446	2614	10T126

7447	2616	10T127
7458	2639	10T128
7451	2641	10T129
7452	2654	SELCY2
7453	2668	10T138
7454	2781	10T131
7455	2728	10T132
7456	2724	10T133
7457	3686	RSRCH8
7468	3687	10T134

7461	3615	RSRCH1
7462	3617	10T135
7463	3628	10T136
7464	3632	10T13A
7465	3642	10T137
7466	3622	10T138
7467	3648	RSRCH2
7478	3654	RSTURN
7471	4896	10T139
7472	4112	10T148
7473	4114	10T141
7474	4281	10T142
7475	4283	10T143
7476	4246	10T144
7477	4258	10T145
7588	4486	SRCH8
7581	4487	10T146
7582	4415	SRCH1
7583	4417	10T147
7584	4428	10T148
7585	4422	10T149
7586	4432	10T14A
7587	4442	10T158
7518	4454	10T158
7511	4448	SRCH2
7512	3733	10T151
7513	3734	10T15A
7514	4514	10T152
7515	4516	10T153
7516	4274	10T154
7517	4548	10T155
7528	4542	10T156
7521	4646	10T157
7522	4651	10T158
7523	4653	10T159
7524	4642	10T168
7525	4614	10T16A
7526	4612	READ1
7527	4664	10T161
7538	4674	10T162
7531	4676	10T163
7532	4782	10T164
7533	4784	10T165

7534	4710	10T166
7535	4712	10T167
7536	4272	10T168
7537	4277	10T169
7540	4381	10T170
7541	2110	10T171
7542	2044	10T172
7543	2071	10T173
7544	2073	10T174
7545	2102	10T175
7546	2104	10T176
7547	2106	MODEND, 10T177

5

0100	4110
0101	4245
0102	4200
0103	4225
0104	2701
0105	1000
0106	5076
0107	6777
0170	7752
0171	7756
0172	0077
0173	4707
0174	2234
0175	3000
0176	0212
0177	0215

0000	00000000	00000001	11111111	111111f1	11111111	11111111	f111f111	11f11111
0100	11111111	11110000	00000000	00000000	00000000	00000000	f111f111	11f11111
0200	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
0300	11111111	11111111	11111111	11111111	11111111	11111111	f111f111	11f11111
0400	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
0500	11111111	11111111	11111111	11111111	11111111	11111111	f111f111	11f11111
0600	11111111	111111f1	11111111	111111f1	f1111111	11111111	f111f111	11f11111
0700	11111111	111111f1	11111111	11f111f1	f0000000	00000000	00000111	11f11111
1000	11111111	111111f1	11111111	111111f1	f1111111	11111111	f111f111	11f11111
1100	11111111	111111f1	11111111	111111f1	f1111100	00000000	0000f111	11f11111
1200	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
1300	11111111	11111111	11111111	11111111	11111111	11111111	f00f1111	11f11111
1400	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
1500	11111111	111111f1	11111111	111111f1	f1111111	11110001	f111f111	11f11111
1600	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
1700	11111111	111111f1	11111110	00000000	00000000	00000000	00000011	11f11111
2000	11111111	111111f1	11111111	111111f1	f1111111	11111111	f111f111	11f00000
2100	11111111	111111f1	11111111	111111f1	f1111111	11111000	0000f111	11f11111
2200	11111111	111111f1	11111111	111111f1	f1111111	11111111	f111f111	11f11111
2300	11111111	111111f1	11111111	111111f1	11000000	00000000	00000111	11f11111
2400	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
2500	11111111	111111f1	11111110	00000000	00000000	00000000	0011f111	11f11111
2600	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
2700	11111111	111111f1	11111111	111111f1	11111100	00000000	f111f111	11f11111
3000	11111111	111111f1	11111111	111111f1	f1111111	11111111	f111f111	11f11111
3100	11111111	111111f1	11111111	111111f1	11110111	11111111	f111f111	11f11111
3200	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
3300	11111111	111111f1	11111111	11000000	00000000	00000000	00000000	00000111
3400	11111111	111111f1	11111111	111111f1	11111111	11111111	f111f111	11f11111
3500	11111111	111111f1	11100000	00000000	00000000	00000000	00000000	00001111
3600	11111111	111111f1	11111111	111111f1	f1111111	11111111	f111f111	11f11111
3700	11111111	111111f1	11111111	111111f1	f0000000	00001111	f111f111	11f11111

4000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
4100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
4200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
4300	11111111	11111111	11111111	11111100	00000000	00000000	00011111	11111111
4400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
4500	11111111	11111111	11111111	11111111	11111100	00000001	11111111	11111111
4600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
4700	11111111	11111111	11111111	11111111	11111000	00000000	00000000	11111111
5000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
5100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
5200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
5300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
5400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
5500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
5600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
5700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
6000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
6100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
6200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
6300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
6400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
6500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
6600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
6700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
7000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
7100	11111111	11111111	10000000	00000000	00000000	00000000	00000000	00000000
7200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
7300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
7400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
7500	11111111	11111111	11111111	11111111	11111111	00000000	00000000	00000000
7600								
7700								

AUTO	0017	DISEND	2284	107102	2007	107149	4422
BADBLK	4461	DIBLUP	2206	107103	2014	10714A	4432
BLK	0027	DIBTRK	2285	107104	2000	10715	0012
BLKCH	2100	DIMLT	0000	107105	2007	107100	4442
BLKCHK	2400	ENDE	2404	107106	2000	107151	3733
BLKCN	0000	ERR1M7	0025	107107	2042	107192	4514
BLKEND	0070	ERR2M7	0056	107108	2047	107193	4516
BLKERR	2146	ERRDR1	0476	107109	2093	107194	4274
BLKHRR	2426	ERRDR2	0007	10711	0442	107195	4540
BLKREY	0061	FBLKCT	2123	107110	2049	107196	4542
BLKSER	0101	FILDCY	3440	107111	2204	107197	4646
BLKTRY	0055	FILDDY	3442	107112	2211	107198	4691
BMESS	4105	FILDEC	3481	107113	2213	107199	4693
BUFF1	7200	FILDPT	3441	107114	2207	10719A	3734
BUFF2	7400	FILICT	3416	107115	2241	10719B	4494
CAP	6007	FILIDY	3400	107116	2293	10710	0021
CCNTR	3224	FILINC	3400	107117	2402	107100	4042
CHKCHK	4323	FILIPY	3447	107118	2410	107101	4044
CHKCLA	0400	FILLS	3227	107119	2413	107102	4074
CHKDAT	4131	FILLPC	3241	10712	0497	107103	4076
CHKERR	4110	FILLSP	3242	107120	2510	107104	4702
CHKHLY	4120	FILL1	3243	107121	2512	107105	4704
CHKHES	4132	FILL1C	3206	107122	2500	107106	4710
CHKSUM	4744	FILL1P	3207	107123	2522	107107	4712
CLOOP	0266	FILL25	3200	107124	2005	107100	4272
CLRWT	4271	FILL2C	3273	107125	2006	107109	4277
CNTR1	0022	FILL2K	3274	107126	2014	10710A	4014
CNTR2	0023	FILL2P	3275	107127	2016	10717	0033
COMLUP	3212	FILLC1	3303	107120	2035	107170	4301
COMP	3916	FILLC2	3304	107129	2041	107171	2110
COMPAR	3200	FILLP1	3321	10713	0461	107172	0040
COMREG	0236	FILLP2	3322	107130	2040	107173	0071
CRLF	0040	FILPAT	3276	107131	2701	107174	0073
CS DLC	0405	FILPL1	3303	107132	2720	107175	0102
CS DLD	0441	FILPL2	3307	107133	2724	107176	0104
CS DRC	0422	FILPNT	0030	107134	3007	107177	0106
CS DRD	0456	FILTC	3331	107135	3017	10718	0042
CSUHR	4303	FILYP	3325	107136	3020	10719	0070
DATA	2452	FORNT1	0032	107137	3042	1072	0212
DATERR	4000	FWDEXP	2422	107130	3022	10720	0074
DATND	0040	GOOD	0024	107139	4004	10721	0077
DATHLT	0036	GPNT*	3295	10713A	3032	10722	0713
DAYLUP	0232	GUARD	2472	10714	0000	10723	0720
DAYNES	0042	HEAD1	0025	107140	4112	10724	0732
DATNUM	0020	HEAD2	0026	107141	4114	10725	1004
DATPNT	0041	HEADTP	4000	107142	4201	10720	1000
DATREG	0201	IN	0021	107143	4203	10727	1011
DBLOCK	0200	INITSY	0005	107144	4246	10720	1012
DIBBL	0250	IOY1	0207	107145	4250	10720	1032
DIBBLK	2233	IOY10	0425	107146	4407	1073	0214
DISDA	0057	IOY100	2004	107147	4417	10730	1030
DISDAT	2236	IOY101	2005	107140	4420	10731	1042

10T32	1844	10T82	1685	MESS34	6157	PASS	3513
10T33	1898	10T83	1687	MESS35	6177	PREFIN	2462
10T34	1853	10T84	1613	MESS36	6231	QBLUP	1874
10T35	1857	10T85	1626	MESS37	6292	QUAD	1824
10T36	1861	10T86	1627	MESS38	6276	QUADR	1841
10T37	1867	10T87	1631	MESS39	6324	QUAD1	1101
10T38	1872	10T88	1635	MESS4	5854	QUAD2	1118
10T39	1116	10T89	1641	MESS43	6352	QUAD3	1138
10T4	2244	10T9	8423	MESS44	6415	QUAD4	1282
10T48	1125	10T98	1694	MESS45	6441	QUAD5	1221
10T41	1133	10T91	1695	MESS46	6466	QUAD6	1248
10T42	1137	10T92	1697	MESS47	6517	QUAD7	1265
10T43	1289	10T93	1664	MESS48	6558	RADDR	4957
10T44	1211	10T94	1698	MESS49	6584	RBLKCT	2132
10T45	1224	10T95	1783	MESS5	5876	RCNT	4856
10T46	1238	10T96	1784	MESS55	6648	RCOUNT	4868
10T47	1242	10T97	1786	MESS51	6693	RDIHRK	2587
10T48	1244	10T98	1713	MESS52	6664	RDIHRK	2515
10T49	1259	10T99	1717	MESS53	6786	RDIQUAD	4787
10T5	2246	LOCKED	4465	MESS54	6738	READ	4888
10T58	1254	LOCK	2445	MESS55	6744	READ1	4812
10T51	1278	LOOP1	8846	MESS56	6747	READ2	4832
10T52	1271	MS288A	4789	MESS57	7812	READR	3714
10T53	1273	MS	8854	MESS58	7825	REYBLK	2476
10T54	1276	MESSAGE	2264	MESS59	7837	REYEXP	2582
10T55	1389	MESS1	3888	MESS6	5183	REYGRD	4661
10T56	1324	MESS18	3174	MESS68	7898	RLOC90	3649
10T57	1325	MESS11	3282	MESS61	7862	ROCK	2237
10T58	1327	MESS12	3283	MESS62	7875	RSEARCH	3688
10T59	1342	MESS13	3285	MESS63	7187	RBLOCK	3678
10T6	8313	MESS14	3286	MESS7	5136	RSEARCH	3686
10T68	1418	MESS15	3289	MESS8	5151	RSEARCH	3613
10T61	1417	MESS16	3293	MESS9	5161	RSEARCH	3648
10T62	1424	MESS17	3416	MODCON	7226	RSTURN	3654
10T63	1442	MESS18	3441	MODCON	7223	RVGARD	2436
10T64	1447	MESS19	3471	MODEND	7247	RXCOR	4714
10T65	1453	MESS2	3821	MODIFY	7288	SBWORD	4749
10T66	1469	MESS28	3516	MODLUP	7287	SDLC	6774
10T67	1466	MESS21	3546	MODH81	7221	SDLD	6779
10T68	1478	MESS22	3544	MODH82	7222	SDRC	6776
10T69	1475	MESS23	3613	MODPT1	7224	SDRD	6777
10T7	8328	MESS24	3635	MODPT2	7225	SDSG	6773
10T78	1588	MESS25	3696	MODTR	7227	SDSS	6771
10T71	1584	MESS26	3788	MODTAB	7238	SDST	6772
10T72	1518	MESS27	3722	MPNTR	2359	SEARCH	4688
10T73	1523	MESS28	3744	OGNT	2341	SELECT1	2634
10T74	1524	MESS29	3773	OK	2744	SELECT2	2654
10T75	1531	MESS3	3844	ONUNB	2348	SELECT	2688
10T76	1532	MESS38	6886	OPLOOP	2384	SELENR	4229
10T77	1533	MESS31	6892	OPRINT	2316	SELHLT	4234
10T78	1543	MESS32	6181	OUT	8829	SELHES	4238
10T8	8486	MESS33	6148	PABCNT	3497	SING1	8636

SING2	8645	WRITE2	4321
SING3	8669	WRITER	3671
SING4	8784	WRORRR	4288
SING5	8723	WRORLY	4212
SING6	1882	WRQUAD	4781
SING7	1881	WRTLOCK	3781
SINGL8	8615	WRRL1	3885
SINGL9	8689	WRRL2	3876
SLOOK	4478	XPER	3888
SP1CT	3456	XXX	4382
SP1PT	3457		
SP2CT	3474		
SP2PT	3475		
SPEC1	3443		
SPEC1D	3468		
SPEC2	3461		
SPEC2D	3476		
SRCH8	4486		
SRCH1	4415		
SRCH2	4448		
SUNIT	4471		
TIME8	1334		
TIME1	1393		
TIME2	1482		
TIME3	1482		
TIME4	1445		
TIME5	1463		
TIME6	1521		
TIMING	1315		
TPNTR	3226		
TYMERR	4249		
TYMHLT	4268		
TYMHES	4262		
TYPE	8831		
UMESS	4182		
UNIT	2234		
UTSMK1	1684		
UTSMK2	1632		
UTSMK3	1781		
UTSMK4	2882		
UTSMK5	2835		
UTSMK6	2842		
UTSMK8	1688		
WADDR	4344		
WCNT	4478		
WCOUNT	4545		
WLB	2673		
WLB	2717		
WRDMES	4214		
WREAD	3824		
WRITE	4472		
WRITE1	4912		

ERRORS DETECTED: 8

LINKS GENERATED: 147

RUN-TIME: 21 SECONDS

3K CORE USED

